

SIMATIC NET NCM for Industrial Ethernet Manual

for NCM S7 V5.1 and higher

Preface, Contents

Communication via Ethernet CPs
in S7 Stations

1

Installing and Starting the Ether-
net CP with STEP 7

2

SEND/RECEIVE
interface in the User program

3

Configuring Communication
Connections

4

Programming Functions (FCs)

5

NCM S7 Diagnostics

6

Firmware Loader

7

References

A

Glossary

B

Linking to Other Systems with
FETCH/WRITE

C

SIMATIC NET Support and
Training

D

Index

12/2001

C79000–G8976–C129

Release 05

Classification of Safety-Related Notices

This manual contains notices which you should observe to ensure your own personal safety, as well as to protect the product and connected equipment. These notices are highlighted in the manual by a warning triangle and are marked as follows according to the level of danger:



Danger

indicates that death or severe personal injury **will** result if proper precautions are not taken.



Warning

indicates that death or severe personal injury **can** result if proper precautions are not taken.



Caution

with warning triangle indicates that minor personal injury can result if proper precautions are not taken.

Caution

without warning triangle indicates that damage to property can result if proper precautions are not taken.

Notice

indicates that an undesirable result or status can result if the relevant notice is ignored.

Note

highlights important information on the product, using the product, or part of the documentation that is of particular importance and that will be of benefit to the user.

Trademarks

SIMATIC®, SIMATIC HMI® and SIMATIC NET® are registered trademarks of SIEMENS AG.

Third parties using for their own purposes any other names in this document which refer to trademarks might infringe upon the rights of the trademark owners.

Safety Instructions Regarding your Product:

Before you use the product described here, read the safety instructions below thoroughly.

Qualified Personnel

Only **qualified personnel** should be allowed to install and work on this equipment. Qualified persons are defined as persons who are authorized to commission, to ground, and to tag circuits, equipment, and systems in accordance with established safety practices and standards.

Correct Usage of Hardware Products

Note the following:



Warning

This device and its components may only be used for the applications described in the catalog or the technical description, and only in connection with devices or components from other manufacturers which have been approved or recommended by Siemens.

This product can only function correctly and safely if it is transported, stored, set up, and installed correctly, and operated and maintained as recommended.

Before you use the supplied sample programs or programs you have written yourself, make certain that no injury to persons nor damage to equipment can result in your plant or process.

EU Directive: Do not start up until you have established that the machine on which you intend to run this component complies with the directive 89/392/EEC.

Correct Usage of Software Products

Note the following:



Warning

This software may only be used for the applications described in the catalog or the technical description, and only in connection with software products, devices, or components from other manufacturers which have been approved or recommended by Siemens.

Before you use the supplied sample programs or programs you have written yourself, make certain that no injury to persons nor damage to equipment can result in your plant or process.

Prior to Startup

Prior to startup, note the following:

Caution

Prior to startup, note the information and follow the instructions in the latest documentation. You will find the ordering data for this documentation in the relevant catalogs or contact your local Siemens office.

Copyright © Siemens AG 2001 All rights reserved

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Siemens AG
Automation and Drives
Postfach 4848, D-90327 Nuernberg

Disclaimer of Liability

We have checked the contents of this manual for agreement with the hardware and software described. Since deviations cannot be precluded entirely, we cannot guarantee full agreement. However, the data in this manual are reviewed regularly and any necessary corrections included in subsequent editions. Suggestions for improvement are welcomed.

Technical data subject to change.

Preface

Purpose

This manual supports you when using the communication services provided by the SIMATIC NET communications processors (Industrial Ethernet CPs) for communication on SIMATIC NET with Industrial Ethernet in the management and cell areas.

The manual contains information about the following topics:

- The performance and areas of application of the communication services
- Configuring the CP with the NCM S7 configuration software
- Programming the communication interfaces to the user program

Audience

This manual is intended for personnel responsible for installing and programming STEP 7 programs and for service personnel.

Scope of this Manual

This manual applies to version 5.1 and higher of the NCM S7 configuration software and to version 5.1 and higher of the STEP 7 software.

New in this version



This version of the manual includes information relating to new functions in STEP 7 and NCM S7 as of V5.1 Service Pack 3.

In the main, this involves the following topics:

- Configuring multicast and broadcast on UDP connections. See Section 4.
- The blocks AG_SEND and AG_RECV can now be used for “long data packets” with an S7–300. See Section 5.
- The S7 CPs for Ind. Ethernet are now supplied with a default MAC address allowing configuration data to be downloaded over Ethernet without a “node initialization”.

The following innovations were already included in the previous version:

- The FETCH/WRITE mode is now supported on TCP connections. See Chapter 4.
- The FETCH/WRITE mode can be coordinated in the user program by the new FCs AG_LOCK and AG_UNLOCK. See Chapter 5.
- NCM Diagnostics has a completely revised user interface. See Chapter 6

The description of NCM S7 Diagnostics has been restructured. While this manual provides you with an overview and checklists, the online help provides you with detailed information on the diagnostic events.

Additional Information

This manual is also part of the NCM S7 for Industrial Ethernet documentation package. The following table provides you with an overview.

Title	Content
<p>NCM S7 for Industrial Ethernet Primer</p> 	<p>Based on simple examples, the primer introduces you to the methods of connecting and networking SIMATIC S7 stations with CPs on Industrial Ethernet. The primer shows you how the communications calls are entered in the user program to allow you to use the services via the SEND/RECEIVE interface.</p> <p>You will learn how simple it is to create a configuration for standard applications using STEP 7 and the NCM S7 optional package.</p> <p>The examples described here can also be found in the project folder for sample programs after you have installed STEP 7 and the NCM S7 for Industrial Ethernet option!</p>
<p>NCM S7 for Industrial Ethernet Manual</p>	<p>The manual is intended as a guide and reference work for configuring and programming an Industrial Ethernet CP.</p> <p>When working with the configuration software, you can also call up the online help in specific situations.</p>
<p>IT-CP Manual</p>	<p>The manual is intended as a guide and source of reference when working with the IT-CP. In addition to the functions provided by an Ethernet CP, the IT-CP also provides functions for Internet technology.</p>
<p>Product Information / Manual for Ethernet CP</p>	<p>The product information bulletins / manuals accompanying the CPs contain information about the specific characteristics of the particular CP and instructions on installation and connections.</p>

Quick Start CD: Samples covering all aspects of communication



The Quick Start CD that can be ordered separately is a treasure-trove of sample programs and configurations.

You can order this directly on the Internet at:

http://www.ad.siemens.de/csi/net/html_00/online_zugreifen.htm

Additional Information on SIMATIC S7 and STEP 7

The following documentation contains additional information about the STEP 7 standard software of the SIMATIC programmable controllers and can be obtained from your local Siemens office.

Topic	Document
Basic information for technical personnel using the STEP 7 standard software for control tasks with S7–300/400 programmable controllers.	STEP 7 basics with <ul style="list-style-type: none"> • Configuring hardware with STEP 7 • Programming with STEP 7 • Manual for converting from S5 to S7 • Primer for a fast start
The reference works describing the programming languages LAD/FBD and STL as well as the standard and system functions in addition to the STEP 7 basic knowledge.	STEP 7 reference manuals with <ul style="list-style-type: none"> • Manuals for LAD/FBD/STL • Standard and system functions for S7–300/400

Access to Online Help of STEP 7 and NCM S7

With the online help, you can obtain the following information:

- Contents with the **Help → Contents** menu command
- Context-sensitive help on the selected object using the **Help → Help** menu command, the **F1** function key or the **question mark** in the toolbar.

You can then access further information relating to the current topic.

- Glossary for all STEP 7 applications by clicking the “**Glossary**” button.

Please note that each STEP 7 application has its own contents and context-sensitive help.

Conventions

References to other manuals and documentation are indicated by numbers in slashes /.../. These numbers refer to the titles of manuals listed in the References section of the Appendix.



Tip:

This symbol appears in the margin to draw your attention to useful tips.



Contents

	Preface	5
	Contents	9
1	Communication via Ethernet CPs in S7 Stations	13
1.1	Industrial Ethernet	14
1.2	SIMATIC S7 Communication with S7 Ethernet CPs	15
1.3	PG/OP Communication via Industrial Ethernet	18
1.3.1	Using a PG with STEP 7 on Industrial Ethernet	20
1.3.2	OP Operation: Connecting Operator Interface Devices via Industrial Ethernet	21
1.4	S7 Communication on Industrial Ethernet	22
1.5	S5-Compatible Communication (SEND/RECEIVE Interface)	24
1.6	FETCH/WRITE Services (Server)	27
1.7	Networking Stations with STEP 7	28
1.7.1	Network/Project Variant: One Subnet – One Project	30
1.7.2	Network/Project Variant: SIMATIC S5 and Non-SIMATIC Devices on the Subnet	31
1.7.3	Network/Project Variant: Two or More Subnets – One Project	32
1.7.4	Network/Project Variant: One Subnet – More Than One Project	33
1.7.5	Network/Project Variant: Two or More Subnets in More Than One Project	34
1.7.6	Network/Project Variant: Connections between Subnets (TCP/IP)	35
2	Installing and Starting the Ethernet CP with STEP 7	37
2.1	General Information About the NCM S7 for Industrial Ethernet Option ..	38
2.2	Procedure	39
2.2.1	Creating an Industrial Ethernet Subnet	40
2.2.2	Entering an Ethernet CP in the Hardware Configuration	42
2.2.3	Displaying the Network Attachments of a Station	44
2.2.4	Setting Further CP Properties	46
2.2.5	“Substitute Objects” in the STEP 7 Project	50
2.2.6	Configuring Communication Services	53
2.2.7	Downloading the Configuration to the PLC	54
3	SEND/RECEIVE Interface in the User Program	57
3.1	How the SEND/RECEIVE Interface Works on the CPU	58
3.2	Programming the SEND/RECEIVE Interface	59
3.3	Data Exchange S7 CPU <-> Ethernet CP	62
3.4	Additional Information	64
3.4.1	Programming Data Transfer on TCP Connections	64
3.4.2	Recommendations for Use with a High Communications Load	65
4	Configuring Communication Connections	67
4.1	Procedure	68
4.2	Possible Connection Configurations	69

4.3	Connections	70
4.3.1	Creating a New Connection	73
4.3.2	Connections to Partners in Other Projects	75
4.3.3	Further Functions	77
4.3.4	Connections Without Assignment	78
4.4	Configuring ISO Transport Connections	81
4.4.1	Specifying the Local Connection Endpoint	82
4.4.2	Specifying ISO Transport Addresses	84
4.4.3	Specifying ISO Transport Dynamic Properties	87
4.4.4	ISO Transport with the FETCH/WRITE Mode	89
4.4.5	Checking ISO Transport Connection Properties	91
4.5	Configuring ISO-on-TCP Connections Properties	93
4.5.1	Specifying the Local Connection Endpoint	94
4.5.2	Specifying ISO-on-TCP Addresses	96
4.5.3	ISO-on-TCP with the FETCH/WRITE Mode	99
4.5.4	Checking ISO-on-TCP Connection Properties	101
4.6	Configuring TCP Connection Properties	102
4.6.1	Specifying the Local Connection Endpoint	103
4.6.2	Specifying TCP Addresses	105
4.6.3	TCP with the FETCH/WRITE Mode	108
4.6.4	Checking TCP Connection Properties	110
4.7	Configuring UDP Connection Properties	112
4.7.1	Specifying the Local Connection Endpoint	113
4.7.2	Specifying UDP Addresses	115
4.7.3	UDP with Broadcast and Multicast	119
4.7.4	Checking the Properties of a UDP Connection	123
4.7.5	Free UDP Connection	125
4.8	Routing to Distribute Load	126
5	Programming FCs (Functions) for S7 Ethernet CPs	127
5.1	General Notes on FCs	128
5.2	Setting Parameters for FC Calls	131
5.2.1	Parameters for CP and Connection Assignment (input parameters)	131
5.2.2	Parameters for Specifying a CPU Data Area (input parameters)	133
5.2.3	Status Information (output parameters)	133
5.3	FCs for Configured Connections	134
5.3.1	FC5 AG_SEND / FC50 AG_LSEND	138
5.3.2	FC6 AG_RECV / FC60 AG_LRECV	144
5.4	FCs for Access Coordination with FETCH/WRITE	150
5.4.1	FC7 AG_LOCK	152
5.4.2	FC8 AG_UNLOCK	154
5.5	Numeric Data / Resource Requirements of the FCs	156
6	NCM S7 Diagnostics	157
6.1	Overview	158
6.2	Functions of NCM S7 Diagnostics	159
6.2.1	Installing and Starting NCM S7 Diagnostics	160
6.2.2	General Menu Commands	162

6.3	Starting Diagnostics – Establishing a Connection to the Ethernet CP . . .	164
6.4	How to Use Diagnostics	167
6.5	Call-Specific Diagnostic Functions	168
6.6	Checklist for ‘Typical Problems’ in a System	170
6.6.1	Checklist for General CP Functions	171
6.6.2	Communication Connections Checklist	172
7	Firmware Loader	173
7.1	Application	174
7.2	Loading Firmware	175
A	References	175
B	Glossary	179
B.1	General Section	180
B.2	Ethernet	184
C	Linking to Other Systems with FETCH/WRITE	187
D	SIMATIC NET – Support and Training	193
	Customer Support, Technical Support	193
	Index	197



Communication via Ethernet CPs in S7 Stations

1

The Ethernet CP for SIMATIC S7 provides a series of communications services for different tasks.

This chapter explains the following:

- The types of communication possible with the Ethernet CP on Industrial Ethernet
- The tasks handled by the Ethernet CP for the various services
- How to create the conditions for your communications requirements



You will find further information in the following sources:

- When installing the Ethernet CP, please refer to the instructions in the product information /1/supplied with the Ethernet CP . This also contains further information about the performance of the Ethernet CP .
- For the functions and use of the STEP 7 configuration software, some of which is used to configure the CP (such as hardware configuration), please refer to /5/ and /7/.
- For using, structuring and handling Industrial Ethernet, you will find detailed information in /10/.
- For a general introduction to local area networks with TCP/IP refer to /15/ and /16/.

1.1 Industrial Ethernet

Definition

Within the open, heterogeneous SIMATIC NET communication system, Industrial Ethernet is the network for the management and cell level. Physically, Industrial Ethernet is an electrical network that uses a shielded coaxial cable or twisted pair or an optical network with fiber-optic cables.

Industrial Ethernet is defined by the international standard IEEE 802.3 (see /10/).

All-Round Communication in the Industrial Sector

Industrial Ethernet is integrated in the SIMATIC NET concept that allows comprehensive networking of the management, cell and field levels in conjunction with PROFIBUS and the AS-interface (AS-i).




Figure 1-1 Industrial Ethernet in the SIMATIC NET Concept

Network Access

Industrial Ethernet is accessed using the CSMA/CD (Carrier Sense Multiple Access with Collision Detection) network access technique specified in IEEE 802.3.

1.2 SIMATIC S7 Communication with S7 Ethernet CPs

Type of Communication

The Ethernet CP for SIMATIC S7 supports the following types of communication depending on the CP type:




Figure 1-2 Types of Communication/Services of the Ethernet CP

- **PG/OP Communication**

PG/OP communication is used to download programs and configuration data, to run test and diagnostic functions and operate and monitor a plant while working at an OP.

- **S7 Communication**

The S7 communication forms a simple and efficient interface between SIMATIC S7 stations and PGs/PCs using communication function blocks.

- **S5-compatible communication**

- SEND/RECEIVE interface

Depending on the CP type, the SEND/RECEIVE interface allows program-controlled communication on a configured connection from a SIMATIC S7 PLC to another SIMATIC S7 PLC, to a SIMATIC S5 PLC, to PCs/PGs, and to any other station.

- FETCH/WRITE services (server)

The FETCH/WRITE services (server) allow direct access to the system memory areas on the SIMATIC S7 CPU from SIMATIC S5 or from devices of other ranges.

- **HTML Process Control**

With the IT-CP, you use the supplied functions and HTML pages to query important system data using a web browser (refer to the IT-CP manual for more information /4/).

- **File Management and File Access with FTP**

The IT-CP (S7-400) provides additional function for FTP services.

You can use your S7 station both as an FTP client and as an FTP server (refer to the manual of the IT-CP /4/).

- S7 Station as FTP Client

You can transfer data blocks from or to a file server.

- S7 Station as FTP Server

Another station, for example, a PC transfers data blocks to or from the S7 station the file system on the IT-CP.

Communication Services on the SEND/RECEIVE Interface

Depending on the CP type, the following communication services are available:

- ISO Transport
optimized for top performance at the self-contained manufacturing level
- TCP/IP for internetwork communication with
 - ISO-on-TCP connections (RFC 1006)
 - TCP connections
 - UDP datagram service (including broadcast / multicast)
- Sending E-mail
 - The controller is capable of sending messages triggered by process events (refer to the IT-CP manual for details).

Possibilities for Communication between Types of Device

The possible communication available with the types of communication listed above is shown in the following table:

	 S7-300	 S7-400	 S5-115 to -155U/H	 PC
 S7-300	S7 communication SEND/RECEIVE	S7 communication SEND/RECEIVE	SEND/RECEIVE FETCH/WRITE	PG/OP communication ¹⁾ S7 communication ¹⁾ SEND/RECEIVE FETCH/WRITE HTML process control
 S7/M7-400	S7 communication SEND/RECEIVE	S7 communication SEND/RECEIVE FTP services	SEND/RECEIVE FETCH/WRITE	PG/OP communication ¹⁾ S7 communication ¹⁾ SEND/RECEIVE FETCH/WRITE HTML process control FTP services

1) PC only as client

Configuration and Diagnostics

To connect and configure the Ethernet CP, you require the STEP 7 configuration software and the SIMATIC NET NCM S7 for Industrial Ethernet option.

NCM S7 for Industrial Ethernet is installed as a STEP 7 option and is therefore integrated in STEP 7.

NCM S7 for Industrial Ethernet also provides a wide range of diagnostic functions for the various types of communication.

1.3 PG/OP Communication via Industrial Ethernet

Application

PG/OP communication provides functions that are already integrated in every SIMATIC S7/M7/C7 device.

A distinction must be made between the following two types of function:

- PG Operation

PG operation with STEP 7 PLCs on Industrial Ethernet means the following:

- You can use the complete range of functions of STEP 7 on Industrial Ethernet.
- You can use programming, diagnostic, operating and monitoring functions on all modules in the SIMATIC S7 PLC via Industrial Ethernet.

- OP Operation

PG/OP communication on Industrial Ethernet allows the operation and monitoring of all modules in a SIMATIC S7 PLC using operator interface systems (TD/OP).

The Ethernet CP acts as a “communications relay” that relays the PG/OP communication via Industrial Ethernet.




Figure 1-3 Configuration for PG/OP Operation

1.3.1 Using a PG with STEP 7 on Industrial Ethernet

Requirement for PG Operation

PG operation is possible when the following requirements are met:

- An Ethernet CP must be installed on the PG.
- The Ethernet CP must have an address (default MAC address or set the IP address).

Networking the PG

To be able to use a PG on Industrial Ethernet, follow the steps outlined below:

1. Connect the SIMATIC S7 stations you want to reach with the programming device to Industrial Ethernet.
 2. Configure the stations via the MPI interface so that the hardware configuration and the networking parameters are loaded. Follow the instructions in Section 2.2 to network the Ethernet CP.
1. Open the “Set PG/PC Interface” dialog box in the Windows Control Panel.
 2. Set the PG/PC interface according to the CPs available on your PG and according to the bus attachment (interface parameter assignment used).



For more detailed information, refer to the integrated help system.

After you have worked through these steps, the PG (STEP 7) automatically finds the path to all intelligent modules in your SIMATIC S7 station via Industrial Ethernet.

1.3.2 OP Operation: Connecting Operator Interface Devices via Industrial Ethernet

Requirements

Operation allowing operator interface functions is possible when the following conditions are met:

- The operator interface device has:
 - an Ethernet CP installed
 - SOFTNET S7 for Industrial Ethernet or S7-1413/WIN 95, WIN NT, MS-DOS, Windows installed
- The CPs in the S7 stations have a MAC/Internet address.

Procedure

To be able to use S7 communication, address the required module in the SIMATIC S7 PLC on your operator interface system.



For more detailed information, refer to the description of your operator interface system.

1.4 S7 Communication on Industrial Ethernet

Application

S7 communication via Industrial Ethernet allows program-controlled communication using communication SFBs/FBs and configured S7 connections. Per job, up to 64 Kbytes of user data can be transmitted.

The CP acts as an “S7 communication relay” that passes on the S7 functions via Industrial Ethernet (see /7/).

Stations for S7 Communication

The Ethernet CP supports S7 communication via Industrial Ethernet on the basis of ISO transport and ISO-on-TCP for:

- PC applications with an Ethernet CP and an interface to the SIMATIC S7 PLC for operator intervention, monitoring and control;
- Communication between S7 stations with integrated communication SFBs/FBs.




Figure 1-4 S7 Communication on Industrial Ethernet

Networking S7 Stations

Before you can use S7 communication, you must first network the S7 stations as follows:

1. Attach the CPs of the SIMATIC S7 stations that you want to communicate with to the Ethernet subnet using S7 functions.
2. Configure the stations via the MPI interface so that the hardware configuration and the networking parameters are loaded. Follow the instructions in Section 2.2 to network the Ethernet CP.

Communication in the User Program

You use SFBs (S7-400) in the user program; these system and standard functions are described in detail in /8/.

Configuring Connections for S7 Stations

To use S7 communication for data exchange between two SIMATIC S7 stations, use the connection configuration in STEP 7. For more detailed information, please refer to the STEP 7 description /5/ /7/.

Communication with a PC/PG via the S7 Interface – Procedure

PC operation is possible when the following conditions are met:

- The PC has:
 - an Ethernet CP installed
 - SOFTNET S7 for Industrial Ethernet or S7-1413/WIN 95, WIN NT, MS-DOS, Windows is installed
- The CPs in the S7 stations have a MAC/Internet address (node initialization; see page 23).

To use S7 communication with the SIMATIC S7 PLC from a PC, address **the required CPU module in the SIMATIC S7 PLC that you want to communicate with in your PC application.**



For more detailed information, refer to the manual of the Ethernet CP you are using in the PC /11/.

1.5 S5-Compatible Communication (SEND/RECEIVE Interface ¹)

Application

Using the SEND/RECEIVE interface, your S7 user program has access to S5-compatible communication with configured transport connections.

Data transmission on a configured transport connection is suitable for

- the reliable transmission of related blocks of data between two Ethernet nodes using
 - TCP (see /16//18//19/) with ISO-on-TCP (see /17/) or TCP connection
 - ISO transport connection
- simple (unacknowledged) transfer of related blocks of data (datagram service) between two Ethernet nodes with UDP (User Datagram Protocol) on IP.

The SEND/RECEIVE interface is also suitable for sending E-mail (refer to the manual for the IT-CP /4/).

For TCP applications, there is an active network with IP protocol (see /19/).

ISO Transport Connection

ISO transport provides services for the reliable transfer of data on configured connections. Due to the segmentation of the data, large amounts of data can be transmitted.

Transmission reliability is extremely high due to automatic repetition and additional field check mechanisms. The communications partner confirms reception of data and the sender receives a return value on the SEND/RECEIVE interface.

ISO transport is operated only on Industrial Ethernet and is optimized for high-performance operation at the self-contained manufacturing level.

¹ The **previous name** of the SEND/RECEIVE interface was **S5S5 connections**

IP (Internet Protocol)

For internetwork data transmission, the following services are available with suitable CPs such as the CP 443-1 TCP:

- ISO-on-TCP connection

ISO-on-TCP is intended for reliable, internetwork data transmission.

The ISO-on-TCP service corresponds to the TCP/IP standard (Transmission Control Protocol/Internet Protocol) with the RFC 1006 extension according to layer 4 of the ISO reference model (see /17/).

RFC 1006 extends the TCP protocol by allowing the transmission of blocks of data ("messages") assuming that both partners support RFC 1006.

Transmission reliability is extremely high due automatic repetition and additional field check mechanisms. The communications partner confirms reception of data and the sender receives a return value on the SEND/RECEIVE interface.

- TCP connection

When using the SEND/RECEIVE interface on TCP connections, the Ethernet CP supports the socket interface (for example, Winsock.dll) to TCP/IP found on almost every system (PC or other system).

TCP is intended for reliable internetwork data transmission.

The TCP service complies with the TCP/IP standard (Transmission Control Protocol/Internet Protocol; see /17/).

- UDP connection

UDP is intended for simple internetwork data transmission without confirmation.

If the connection is suitably configured, broadcast and multicast frames can also be sent on UDP connections.

To avoid overload due to high broadcast load, the CP does not allow reception of UDP broadcasts. As an alternative, use the multicast function over a UDP connection. This allows you to register the CP as a node in a multicast group.

SEND/RECEIVE interface

Data transfer is triggered by the user program. The interface to the user program in the SIMATIC S7 is formed by special SIMATIC S7 blocks of the type FC (functions).

Stations

The SEND/RECEIVE interface allows program-controlled communication on Industrial Ethernet between the SIMATIC S7 PLC and the following:

- SIMATIC S7 PLC with Ethernet CP
- SIMATIC S5 PLC with Ethernet CP
- PC/PG with Ethernet CP

- Other station with Industrial Ethernet attachment




Figure 1-5 SIMATIC S7 PLC with Possible Communications Partners on the SEND/RECEIVE Interface

1.6 FETCH/WRITE Services (Server)

Application

In addition to the SEND/RECEIVE interface, the FETCH/WRITE functionality provides further services for S5-compatible communication on configured transport connections.

The FETCH/WRITE interface is used primarily to attach SIMATIC S7 to SIMATIC S5 and to other non-S7 stations (for example PCs).

- **FETCH**

The partner on the connection (SIMATIC S5 or non-S7 station) can read system data on the SIMATIC S7 PLC.

- **WRITE**

The partner on the connection (SIMATIC S5 or non-S7 station) can write system data on the SIMATIC S7 PLC.

From the point of view of the SIMATIC S7 PLC, this is a **passive** communication function; the communications partner initiates the connection establishment.



For further information, refer to the system documentation of the SIMATIC S5 PLC or the non-S7 station you are using.

Connection Types

To access a station with FETCH or WRITE functions, a FETCH passive or WRITE passive connection must be configured. The following types are possible:

- ISO Transport
- ISO-on-TCP
- TCP

Coordinating Access Using the User Program

To coordinate access, you can use the FCs AG_LOCK and AG_UNLOCK.

With these FCs, you can coordinate access to system memory areas so that no inconsistent data are created and transferred.

SIMATIC S5

On the SIMATIC S5 station, the FETCH/WRITE services are configured and started by READ ACTIVE/PASSIVE and WRITE ACTIVE/PASSIVE.

1.7 Networking Stations with STEP 7

Configuring


To allow stations to communicate with each other the networks must be configured in the STEP 7 projects.

Configuring a network or subnet involves the following:

1. You create one or more subnets of the required subnet type in the project.
2. You select the properties of the subnet. Normally the default settings are adequate.
3. You connect the station “logically” to the subnet.
4. You set up connections for communication.

Tools

The SIMATIC Manager provides convenient tools for configuring and documenting networks (also graphically with NetPro).



The chapter describing network configuration in /5/ and the online help system also contain information about configuring SIMATIC S7 networks.

Variants

Before configuring networks with STEP 7, you should be aware of the various configurations possible in the STEP 7 project. The following configurations are typical for stations networked with CPs:


Variant (examples)	Characteristics/Configuration
1	1 subnet – 1 project
2	Additional SIMATIC S5 stations and stations with equipment of other vendors
3	2 or more subnets – 1 project
4	1 subnet – more than one project
5	More than one subnet – more than one project
6	Internetwork connections (ISO-on-TCP)

These variants will be used as a basis to illustrate how real configurations can be created in STEP 7 projects.

1.7.1 Network/Project Variant: One Subnet – One Project


Configuration of the System

In the simplest case, your system consists of SIMATIC S7 stations connected by **one** subnet, for example of the type Industrial Ethernet.



View in a STEP 7 Project


You create an Industrial Ethernet object in the STEP 7 project. Stations created in the same project refer to this object as soon as they are configured as network nodes.



1.7.2 Network/Project Variant: SIMATIC S5 and Non-SIMATIC Devices on the Subnet


Configuration of the System

In addition to SIMATIC S7 stations, SIMATIC S5 stations and non-SIMATIC devices can be included in your system.



View in a STEP 7 Project


SIMATIC S5 stations you intend to include in the communication can be selected directly. Non-SIMATIC devices must be entered in the configuration as **Other stations**.



1.7.3 Network/Project Variant: Two or More Subnets – One Project


Configuration of the System

Due to the different tasks of the stations or due to the extent of the system it may be necessary to operate more than one network.



View in a STEP 7 Project

You can create the subnets in **one** STEP 7 project and configure the stations for communication.




This representation illustrates the following:

- More than one subnet can be managed in one project.
- Each station is created once in the project.
- Each station can be assigned to more than one subnet by assigning its CPs to different subnets.

1.7.4 Network/Project Variant: One Subnet – More Than One Project


Configuration of the System

In complex networked systems, it may be more practical to manage the stations in more than one project.



View in a STEP 7 Project

To be able to address stations that are managed in a different project (production 2), these stations are configured **additionally** as "Other stations" (in the project for production 1).



This representation illustrates the following:

- A subnet can be assigned to several projects.


Note

S7 connections can only be configured within **one** project.

1.7.5 Network/Project Variant: Two or More Subnets in More Than One Project

Configuration of the System


If the different tasks of the stations or the extent of the system mean that different network types are necessary and that the network types must be managed in different projects, the stations in a different project can once again be addressed by configuring them as “Other stations”.



1.7.6 Network/Project Variant: Connections between Subnets (TCP/IP)


Configuration of the System

If connections are required to stations on network structures connected by routers due to the differing tasks of the stations or the large span of the network, the stations in the other project can be reached by configuring “**Other Stations**”.



View in a STEP 7 Project

If the stations in the two networks are managed in the same project, the networking appears as shown below in NetPro.





Installing and Starting the Ethernet CP with STEP 7

2

To attach a SIMATIC station to Industrial Ethernet via the Ethernet CP, configure the CP with the NCM S7 configuration software. The chapter explains the following:

- How the CP is configured in the STEP 7 project
- How the various network configurations are managed (setting up access to other systems)
- How to control and supply the CP with data using NCM S7



You will find further information in the following sources:

- When installing the Ethernet CP, please refer to the instructions in the product information / manual LEERER MERKER supplied with the Ethernet CP. This also contains further information about the performance of the Ethernet CP .
- For more information about the functions and applications of STEP 7 in which the NCM S7 option is integrated, please read the following topics:
 - For using the help functions, read the section Working with STEP 7 in /5/.
 - Configuring and assigning parameters to modules in /5/
 - Configuring networks in /5/. You will find this information in the online help with integrated in STEP 7 by selecting **Help ► Contents**.
- You will find examples of configurations in the Primer /3/.



2.1 General Information About the NCM S7 for Industrial Ethernet Option

Installation

Please follow the instructions in the README file when installing the NCM S7 for Industrial Ethernet option on your PG/PC under STEP 7.

Functions

NCM S7 consists of the following:

- CP-specific index dialogs that you call using the properties dialog box of the modules.
- Dialogs for the connection configuration
- Diagnostic functions that you obtain as follows:
 - Using the “Diagnostics” tab in the properties dialog
 - Using the standard Start menu of Windows with which you can call the SIMATIC program group
- Functions displayed with **SIMATIC ► NCM...** in the Start menu of Windows:
 - Diagnostics
 - Help for functions (FCs)
 - “Readme” file with current information about NCM
 - Firmware loader


Operation

Operating and handling the software package is as explained in the STEP 7 user manual /5/.

2.2 Procedure

A CP is managed in an S7 project just as the other modules. You use STEP 7 to configure the hardware and create and manage the user software (see /5/).

Configuring a CP involves the following basic steps (the broken lines indicate options):



The steps are explained in detail in the sections shown.

Fields with broken lines are optional.

2.2.1 Creating an Industrial Ethernet Subnet

Aims

To be able to attach the SIMATIC stations to a subnet, you create the subnet in your project. This means that all the parameters for the entire subnet are managed centrally.

Procedure

It is advisable to create the subnet before you configure the stations since the assignment of the SIMATIC stations is then performed largely automatically.

It is also possible to create the subnet at a later point in time when configuring a CP. This is explained in more detail later in the chapter.

Follow the steps outlined below:

1. Select the project in the SIMATIC Manager.
2. Select **Insert ► Subnet ► Ethernet**.

Result: An object of the type network is created in the project. This allows all the SIMATIC stations created in the project to be attached to this subnet.




Figure 2-1 Project with Assigned Ethernet Network

3. If you prefer a graphic network display, select the network object "Ethernet" and confirm with **Edit ► Open Object**.




Figure 2-2 Graphic Network Representation (here showing stations not yet networked)

From this graphic representation, you can also activate all the functions for networking and configuring connections with the Ethernet CPs.

2.2.2 Entering an Ethernet CP in the Hardware Configuration

Procedure

By inserting the Ethernet CP in the rack of a SIMATIC station and assigning it to the station, you establish the logical attachment between the CP and subnet.

1. Select the station in your project that you want to attach to Industrial Ethernet using an Ethernet CP.
2. Select the CP in the hardware configuration just like any other module by selecting it in the hardware catalog and then selecting the slot in the rack.

You select CPs in the hardware catalog using a short text and the order number. Once you have installed NCM S7, the CPs are available in the catalog.

Result: The CP is assigned to the SIMATIC station.


For information about the permitted slots, refer to /1/.

How to configure a module is described in detail in /5/.



Subnet Attachment

To allow you to activate the network attachment of the Ethernet CP, the SIMATIC Manager displays the following dialog:



Note

You can open the dialog for setting the interface at any time from the Properties dialog of the CP in the “General” tab.

1. If you have not yet created a subnet in the project or have not yet created the selected subnet, you can now create a subnet. To do this, select the “New” button.

Result: An object of the type network is created in the project.

2. Check the addresses and if necessary change them. The system enters the next free address automatically.
3. Select the required subnet type in the “Subnet” list box.
4. You can display the properties dialog box for the selected subnet by clicking the Properties button.
5. Enter information specific to the subnet node in the “General” tab.
6. You must finally confirm your input with OK, otherwise the networking is not entered (refer to Point 3.).

Result: The CP is now configured as a network node for the corresponding S7 station.

Note

The input boxes “IP address” and “Subnet mask” are irrelevant for ISO transport.

2.2.3 Displaying the Network Attachments of a Station

Procedure

You can easily get an overview of the network attachment configurations of a SIMATIC station in one of the following ways:

- A graphic overview in NetPro;
- An overview in table form in the Properties dialog of the station

Graphic Overview in NetPro

The NetPro view provides you with a good overview of the networked stations:

Follow the steps below:

1. Double-click one of the network objects, for example Ethernet in your project in the SIMATIC Manager.




Figure 2-3 NetPro View of a Subnet of the Type Industrial Ethernet

Overview in Table Form

The table view in the Properties dialog of the station provides a detailed overview of the components used for network attachment.

Follow the steps below:

1. Using the SIMATIC Manager, select the station in your project that you want to check.
2. Select the **Object Properties** using the menu option **Edit ► Object Properties** or by double-clicking the station symbol.
3. Select the “Interfaces” tab.

Result:




Figure 2-4 “Interface” Tab in the “SIMATIC 300/400” Properties Dialog Box

In the displayed dialog, you can see the subnet attachments that were configured for the SIMATIC station.

2.2.4 Setting Further CP Properties

Overview

In addition to the network attachment, you can also make further settings for the specific module or you can call functions.

1. Select the Ethernet CP in the hardware configuration.
2. Select **Edit ► Object Properties**. In the dialog, you will see further tabs in addition to the “General” tab described in Section 2.2.2 depending on the type and CP, some of which are shown in the example of a CP 443-1:




Figure 2-5 Example of the “General” Tab of the “Properties CP” Dialog Box for the CP 443-1 TCP



Please read the description of the Properties dialog of the CP in the integrated help. The functions are explained in detail there.

Addresses Tab

The Addresses tab displays the address at which the module can be addressed by the user program. You require this address when calling the FCs for transport connections → see Chapter 5.

Options Tab

Depending on the CP type, you can make the following settings:

Table 2-1 Settings in the “Options” Tab

Option	Meaning / Effect
<ul style="list-style-type: none"> Time-of-Day Synchronization 	<p>Here, you decide whether the CP passes on time-of-day frames or not. You require this function if you have several CPs in a station since only one CP is permitted to pass on the time synchronization messages.</p> <p>Note The time-of-day synchronization function does not exist for all module types.</p>
<ul style="list-style-type: none"> Data transfer > 240 bytes 	<p>With this option, you specify whether or not the CP will support jobs with a data length of more than 240 bytes (for S7-300 stations).</p> <p>Notes</p> <ul style="list-style-type: none"> The transfer of more than 240 bytes of data is supported by newer version CPs. Please note the information in the product information bulletin / manual of the Ethernet CP.  See also chapter 5 If you select this configuration for an S7-300, remember that a connection resource (free connection for S7 Functions) of the S7-300 CPU is used! CPU connection resources are also used, for example, by S7-300 CPs, in the FMS mode or by PGs and OPs. For more detailed information about the maximum connection resources, refer to /12/ and /6/.
<ul style="list-style-type: none"> Replace Module without PG 	<p>With this option, you can have the configuration data of the CP stored on the CPU. If you then replace CP, the configuration data for the new CP are downloaded automatically from the CPU when the CP is started up.</p> <p>If you select this option, the configuration data are stored long-term on the CPU instead of in the EEPROM of the CP. Remember, however, that long-term storage on the CPU is only safe against power failure if the CPU is battery backed or if you use an S7 memory card.</p>
<ul style="list-style-type: none"> Ethernet Profile for Fault-Tolerant Connections 	<p>Select this profile if you use fault-tolerant communication in your system. Fault-tolerant means that you have designed Industrial Ethernet to include redundant components and that you have configured fault-tolerant S7 connections.</p> <p>If you select the Ethernet profile for fault-tolerant connections here, the time response of the S7 connections is adapted. As a result, breakdowns of a connection are detected more quickly and the failover to redundant connections is faster.</p> <p>Note Select the Ethernet profile for fault-tolerant connections only when you actually use fault-tolerant S7 connections. Otherwise you must expect your system to be more susceptible to problems since, for example, the number of transfer or connection establishment attempts is reduced compared with non-redundant systems.</p>

Table 2-1 Settings in the “Options” Tab , continued

Option	Meaning / Effect
<ul style="list-style-type: none"> Individual Network Settings 	<p>Here, you can make fixed network settings, when necessary. As default, “Automatic Setting” is selected and this setting generally guarantees problem-free communication in most situations.</p> <p>If problems occur in communication (for example, when connections are not established or when there are often disturbances on the network), the reason may be that the selected or automatic network settings are not suitable. You can then select a network setting to suit your network configuration.</p>
<ul style="list-style-type: none"> Send Keepalives for Connections 	<p>Here, you can set the interval at which keepalives are sent to the partner of a communications connection. This setting decides the latest time after which the failure of a communications partner is detected.</p> <p>For all connection-oriented services, the Ethernet CP is configured so that keepalives are sent. This guarantees that connections are closed if a communications partner fails and that the connection resources are released. The setting made here applies to all TCP- and ISO-on-TCP-connections operated via the CP; a connection-oriented setting is not possible.</p> <p>Possible values:</p> <p>Default Setting: 30 seconds</p> <p>Maximum value: 65535 seconds</p> <p>Notes / Recommendations:</p> <p>Remember that the keepalive mechanism can keep underlying connections established (for example, an ISDN telephone connection) although no user data are actually being transmitted. If this is not required, set the interval so high that the underlying connection is closed down when no further user data are sent before a keepalive is sent.</p>

Table 2-1 Settings in the “Options” Tab , continued

Option	Meaning / Effect
<ul style="list-style-type: none"> Multiplex OP Connections / Reserve CPU system resource 	<p>To attach TD/OPs or HMI devices, you can optimize the connection resources on the S7-300 CPU by having up to 16 of these devices communication on a single CPU connection resource (multiplex mode).</p> <p>If you do not use this option, the number of operable TD/OPs or HMI devices depends on the number of available connection resources of the CPU you are using.</p> <p>As default, this option is deactivated. This means that a CPU connection resource is used for multiplex only when necessary.</p> <p>Configured S7 connections over the CP use the same multiplex channel as you use for multiplexing the HMI connections. If you configure S7 connections, this means that one CPU connection resource is already used.</p> <p>Please not the following: PG connections do not use the multiplexer; if you use a PG, one connection resource is always occupied.</p> <p>Note on programming: When you use the multiplex mode, you must specify the rack/slot assignment of the CP for addressing on TD/OP/HMI connections instead of the rack/slot assignment of the CPU!</p> <p>Applications (for example ProAgent) that require block-related messages (Alarm_S: SFC17-19) are not supported in multiplex mode.</p>

Diagnosics Tab

In the “Diagnosics” tab, you can start NCM S7 Ethernet Diagnostics.

See Chapter 6 Diagnostics for a description of the diagnostic functions themselves.

2.2.5 “Substitute Objects” in the STEP 7 Project

Overview


For the following stations on the Ethernet subnet, whose configuration data were not created in STEP 7 or whose configuration data are not managed in the currently active project, substitute objects must be created in the project:

- SIMATIC S5 stations
- Devices from other vendors (other stations)
- PG/PC
- SIMATIC S7 stations in a different project (other stations)

Note

Instead of creating substitute objects, you can also configure unspecified connections for connections to the stations listed above.

In the Properties dialog of these connections, you must then specify the full partner address. These partners do not appear in the NetPro plant view.



Procedure

To enter a substitute object in the project, following the steps below:

1. Select the project in the SIMATIC Manager.
2. Select the menu command **Insert ► Station ►** and then as necessary **Other Station, PG/PC** or **SIMATIC S5**.

Possible result: the selected object is created in the project.




Figure 2-6 Project With Substitute Objects Configured

Attaching Non-S7 Stations to the Subnet

The next step is to assign the substitute objects to the subnet, as follows:

1. Select the required object in the project and select **Edit ► Object Properties**.
2. In the Properties dialog box that is displayed select the Interfaces tab and click the “New” button (for example “Other Station”).

Result: The New Interface – Type Selection dialog box is displayed.




Figure 2-7 Selecting the Subnet Type for “Other Station” (Example)

3. Select a subnet.

Result: The “Properties – Ethernet Interface” dialog is displayed. Here, you can select the subnet, connect the station to the network and set the address (MAC, IP). All the SIMATIC stations in the project can establish communication relationships to this substitute object.

The addresses (MAP/IP) configured for the substitute object here must also be set on the station using the appropriate tool, for example COM 1430.

2.2.6 Configuring Communication Services

Setting Up Connections

You must set up connections for the connection-oriented services supported by the Industrial Ethernet CP, see also the Table in Section 1.2.

- S7 connections
see the STEP 7 user manual /5/
- ISO transport connections
see Section 4.4
- ISO-on-TCP connections
see Chapter 4.5.
- TCP connections
see Section 4.6
- Connections for UDP
see Section 4.7.

The information in the STEP 7 user manual /5/ in the chapter “Creating Communication Connections Between Two Programmable Modules” also applies to the additional types of connection possible with the CPs.



You will find this information in the online help with integrated in STEP 7 by selecting **Help ► Contents**. Select the topic “Configuring Connections and Data Exchange.

2.2.7 Downloading the Configuration to the PLC

Principle

The configuration data of the Ethernet CP are downloaded from the hardware configuration. All the configuration data of the S7 station are downloaded including the central configuration, all relevant DP master systems and all parameter settings.

The data of the **configured connections must also be downloaded**, see below.

Type of Interface

You can download the configuration data to the S7 station on the following paths (interfaces):

- MPI interface

You can use this interface to download configuration data or when assigning a MAC/IP address for the first time (node initialization – for details, refer to the manual /1/ “Assigning Addresses for the First Time”).

- Industrial Ethernet

Here, you use the PG mode of the Ethernet CP in the S7 station (see also Section 1.3). This is only possible if you use the default MAC address or have already assigned a MAC/IP address (node initialization – for details, refer to the manual /1/ “Assigning Addresses for the First Time”).

Procedure

To download the configuration data to the S7 station, follow the steps outlined below:

1. Open the “Set PG/PC Interface” dialog box in the Windows Control Panel.
2. Set the PG/PC interface according to the CPs available on your PG and according to the bus attachment (interface parameter assignment used).

For more detailed information, refer to the integrated help system.

3. Change the CPU to the STOP mode (regardless of the type of interface – see above).

4. Select the menu command **PLC ► Download to Module**.

STEP 7 then guides you through dialog boxes. Note the additional information in the “STEP 7 User Manual”, Chapter “Configuring and Assigning Parameters to Modules” /5/.



Saving the Configuration Data in Non-Volatile Memory

You can download the configuration data step-by-step or all at once. If you download step-by-step, you will be prompted to start the download function separately for each module. You must select this method if you want to save the configuration data in non-volatile memory on the Ethernet CP. In this case, select the "Copy to ROM" button in the "Download" dialog for the CP.

Downloading the Configured Connections

To download configured connections, you use a corresponding download function in the connection configuration (NetPro).

Notice

If you have assigned a new address to the Ethernet CP or have configured connections, you must always download the connection configuration again.

Remember that you also make suitable address adaptations for the other stations or "substitute objects".

Relocating the CP in the Hardware Configuration

If you are using communication services with configured connections, the connection IDs also identify the slot of the CP. If you "drag" a CP you have already configured to a different slot, note the following:

Notice

If you drag the CP to a different slot, the data of the connection configuration are automatically updated. The data of the connection configuration must, however, be downloaded again!



SEND/RECEIVE Interface in the User Program

3

This chapter explains the following:

- How to send and receive data.
- Which data areas can be used on the S7 CPU.
- How to program the SEND/RECEIVE interface in the user program.



You will find further information in the following sources:

- For programming and configuring nodes for connections (for example a SIMATIC S5 PLC with the CP 1430 TCP, PC with CP 1413), please refer to the appropriate manuals.
- The FCs for programming connections are described in Section 5.3.
- Configuring the Ethernet CP with NCM S7 is described in Chapter 4.

Sample programs:



Sample configurations and programs are available for the SEND/RECEIVE interface described here:

- In the sample project PROJECT_ETHERNET that you can start immediately after installing NCM S7; for a description, refer to the Primer /2/.
- On the Internet as downloadable sample projects; refer to the information in Appendix C “Support and Training”.



The Quick Start CD that can be ordered separately is a treasure-trove of sample programs and configurations.

You can order this directly on the Internet at:

[http://www.ad.siemens.de/net/html_00/
online_zugreifen.htm](http://www.ad.siemens.de/net/html_00/online_zugreifen.htm)

3.1 How the SEND/RECEIVE Interface Works on the CPU

Functions (FCs)

The following functions (FCs) are available for handling communication on connections:

- AG_SEND/AG_LSEND
This block takes the user data from the specified user data area and transfers it to the Ethernet CP.
- AG_RECV/AG_LRECV
This block transfers received user data to the user data area specified in the call.

The diagram below illustrates the situation. Using the FCs AG_SEND/AG_LSEND and AG_RECV/AG_LRECV, the user program instructs the Ethernet CP to send or receive data on the configured connection.




Figure 3-1 Interaction of the CPU and Ethernet CP on Connections

Amounts of Data

The Ethernet CP can transfer the amounts of data shown in the table below per job on one connection:

Table 3-1

	ISO Transport	ISO-on-TCP	TCP	UDP
Sending	8192 bytes	8192 bytes	8192 bytes	2048 bytes
Receiving	8192 bytes	8192 bytes	8192 bytes	2048 bytes

3.2 Programming the SEND/RECEIVE Interface

Principle of Job and Data Transfer

The user program triggers the transfer of the user data areas with FC calls and monitors the transfer by evaluating the return codes of the FCs.

The following parameters are transferred when the FCs are called:

- The number of the connection (ID)
- The location of the user data area in the CPU

For detailed information about the call interface see Chapter 5.

Purpose of the FCs

Calling the function blocks has the following effects:

- The user data area is transferred to the Ethernet CP or received from the Ethernet CP.
- The execution of the job is confirmed positively or negatively in a status message.

Programming Connections

Program the SEND/RECEIVE interface in the user program as follows:

1. Use the following functions (FCs) for data transmission on connections:
 - AG_SEND for transferring the user data area to the Ethernet CP
 - AG_RECV for entering data received from the Ethernet CP in the user data area
2. Evaluate the following bits in the FCs:
 - for AG_SEND the parameters DONE, ERROR, STATUS
 - for AG_RECV the parameters NDR, ERROR, STATUS

Notice

Connection numbers (IDs) must be taken from the configuration when programming.

Calling FCs in the CPU Program

One possible sequence for FCs in conjunction with the organization and program blocks in the CPU cycle is illustrated in the following diagram.




Figure 3-2 Typical Sequence of Function Calls in the CPU Cycle

The following points are illustrated by the diagram:

- The user program consisting of any number of blocks (OBs, FBs or FCs → see /5/ accesses several connections (Figure 3-2 illustrates three connections).

- At various points (event and program-controlled) the user program sends data on a connection using the AG_SEND call.
- At various points in the CPU cycle, the user program accepts the data received on the connection using an AG_RECV call.

Note

The blocks can also be called more than once in a cycle for the **same** communication connection.

3.3 Data Exchange S7 CPU <=> Ethernet CP

The Ethernet CP processes the send and receive jobs independent of the CPU cycle and requires one transmission time. The interface to the user program with the FCs is synchronized by an acknowledgment. Two situations must be distinguished:

- The CPU cycle is faster than the transmission time.
- The CPU cycle is slower than the transmission time.

Note

Please refer to the sequence charts for the FCs in Chapter 5. These charts show how to handle the SEND/RECEIVE interface in the user program for problem-free data exchange.

Remember the points below about the CPU cycle and transmission time.

FC Calls Faster than the Transmission Time

If a block is called again in the user program before data were transferred or received, the procedure is as follows on the interface of the FCs:

- AG_SEND/AG_LSEND:
No further job is accepted until the transmission of the data on the connection has been acknowledged by the Ethernet station. During this time, the user program receives the message “job active” until the Ethernet CP can accept the next job on the same connection.
- AG_RECV/AG_LRECV:
The job is acknowledged with the message “no data available yet” if there are no received data on the Ethernet CP. The user program receives this message in the CPU cycle until the Ethernet CP has received data again on the connection.

FC Calls Slower than the Transmission Time

If a block is called again before the data were completely transferred or received, the procedure is as follows on the interface of the FC blocks:

- AG_SEND/AG_LSEND:
The job is positively acknowledged. The Ethernet CP is ready to receive a new send job (at the earliest however with the next call).
- AG_RECV/AG_LRECV:
The job is acknowledged with “New Data Received” when the data have been transferred to the user program. Following this, the FC call can be repeated.

Notice

Remember that resource shortages can occur if the processing speeds on the sender and receiver are not the same (sender faster than receiver).

The sender receives a message from the FCs if problems occur (“No resources on the destination station”).

3.4 Additional Information

3.4.1 Programming Data Transfer on TCP Connections

Purpose of TCP Connections

TCP connections should be used above all for connections to systems of a different type if they do not support RFC1006.

For communication between devices of the SIMATIC family, you should use the more convenient ISO-on-TCP connections! The following sections explain certain special points to note.

Special Features

- Block types (FC calls)

For data transfer, use only FC AG_LSEND (FC 50) and FC AG_LRECV (FC 60).

- Frame length

On the TCP connections, the protocol contains no information about the end of a message and start of a new message.

The receiving station must therefore know how many bytes belong to a message and transfer an ANY pointer corresponding exactly to this length when FC AG_LRECV is called. (Example: if 100 bytes of data are always transferred, the ANY pointer could appear as: P#DB100.DBX 0.0 Byte 100)

If you want to receive data with a variable length, follow the steps below:

Include information on the length of the user data in the frame before the actual user data. In the receiving station, you evaluate only the length information and then fetch the appropriate amount of data in a further receive job.

3.4.2 Recommendations for Use with a High Communications Load

Overview

The points below will help you to avoid overload situations on your CPU when using the Ethernet CPs.

In particular when you replace an older CP with a newer CP and are then confronted with overload problems, you should check your application for the pitfalls outlined below.

Known Problems

- The functions for sending and receiving (FC 5/FC6 or FC 50/60) are often called cyclically in OB1. This leads to constant communication between the CPU and CP. As a result, other types of communication such as PG functions cannot be executed or only very slowly.
- HMI systems access data of the CPU too often using S7 functions. This slows down communication generally and there may be a lack of resources when SEND/RECEIVE FCs are called cyclically in OB1.

Remedy

The recommendations below will help to avoid these situations:

- Do not call communication blocks cyclically in OB1!
Communication should be called time-controlled in a suitable cyclic-interrupt OB. The call interval of this OB should be significantly higher than the average cycle time of your program.
- You should set a minimum cycle time that is higher than the average runtime of OB1. This frees resources for communication on the CPU. This is, for example, a remedy for existing applications when communication already takes place cyclically in OB1.
- If necessary, reduce the time taken for communication processing on the CPU by changing the parameters set for "cyclic load due to communication" in the properties dialog of the CPU.



Configuring Communication Connections

4

This chapter explains the following:

- The general aspects of configuring communication connections
- How to configure ISO transport connections, ISO-on-TCP and TCP connections
- How to use the connection configuration functions to specify communication partners that exchange data via UDP

You will find a description of the connection-specific properties dialogs in the following sections:

- ISO transport connections see Section 4.4
- ISO-on-TCP connections see Section 4.5
- TCP connections see Section 4.6
- UDP see Section 4.7



You will find further information in the following sources:

- For the properties of the configurable connection types, refer to Section 1.5.
- For the properties of the configurable connection type E-mail, refer to /4/.
- You will find information on the numbers of connections and amounts of data in Section 3.1.



- For information on configuring connections, refer to the online help of STEP 7 by selecting **Help ► Contents**.

4.1 Procedure

Steps

The following steps are necessary to operate connections on the SIMATIC S7 PLC with the Ethernet CP:




Figure 4-1 Operating Connections with the Ethernet CP

4.2 Possible Connection Configurations

Connections within a Project

Connections are possible between different communication partners within a project as shown in the following diagram.

Connections to communication partners outside a project are configured using substitute objects such as "Other Stations" or SIMATIC S5.




Figure 4-2 Possible Connections

4.3 Connections

Characteristics of a Connection

A communication connection allows program-controlled communication between two nodes on Industrial Ethernet with the following characteristics:

- The data transfer is bi-directional, in other words, it is possible to transmit and receive on the connection simultaneously.
- Both stations have the same rights, in other words, each station can trigger the send and receive procedures in response to events.
- The address of the communication partner is specified in the configuration.

The free UDP connection is the exception to this. Here, the address is specified at the FC interface in the user program.




Figure 4-3 Sending and Receiving via one Communication Connection

Note

The term “connection” is also used here for UDP. Reason: during configuration (just as in TCP) the communication partners are assigned to each other and therefore logically “connected”. In actual fact, with UDP there is no explicit connection establishment between communication partners.

Amounts of Data

Refer to the product information LEERER MERKER accompanying the Ethernet CP for the number of communication connections supported by the Ethernet CP. The number of connections per station can be increased by adding more CPs.

The Ethernet CP can transfer the amounts of data shown in the table below per job on one connection:

Table 4-1

	ISO Transport	ISO-on-TCP	TCP	UDP
Sending	8192 bytes	8192 bytes	8192 bytes	2048 bytes
Receiving	8192 bytes	8192 bytes	8192 bytes	2048 bytes

Notice

Transfer of more than 240 bytes of data is supported by newer CP versions. Please note the information in Section 5 and in the manual of the Ethernet CP.

Tasks of the Ethernet CP

When handling the data transfer on a connection, the Ethernet CP has the following tasks:

- When receiving
Receiving data from Ethernet and transferring it to the user data area on the CPU.
- When sending
Taking data from the user data area on the CPU and sending the data via Ethernet.

For a free UDP connection, the following functions are also necessary in addition to those above:

- When receiving
Entry of the sender of the message in the job header.
- When sending
Evaluation of the job header and addressing the partner

The connection is established automatically as soon as the partner is obtainable.

Requirements for Configuring Connections

The Ethernet CP was entered in the hardware configuration and connected to the subnet.

As a bus node, the Ethernet CP has an address.

Notice

All stations not in the STEP 7 project must be configured with substitute objects (for example as "SIMATIC S5" or "Other stations").

or

Use the "unspecified" partner type when you create the connection.

4.3.1 Creating a New Connection

Principle

When you create new connections, you start from entered and networked stations. A connection is then configured starting from a station or CPU in the current S7 project and then selecting a destination station.

Due to the networking, the node addresses (MAC or IP addresses) of the two stations are already decided. The local/remote TSAPs (Transport Service Access Point) or ports at both ends of the connection are automatically assigned default values.

If the partner station is a station outside the current project or a non-S7 station, the remote TSAPs (Transport Service Access Point) or ports must be specified in the Properties dialog of the connection.

The endpoint of the connection to a SIMATIC S7 station is always a CPU. A separate connection table is created for each CPU and displays the connection partner and types of connections.

How to Open the Connection Table

You can open the connection table in a variety of ways:

Using the “Start” button in the Windows taskbar **SIMATIC ► STEP 7 ► Configure Networks**, you open the NetPro graphic representation.

In NetPro, follow the steps below:

1. In NetPro, select the station or the CPU in the station from which you want to establish the connection.
2. Select the menu command **Insert ► New Connections** (also available with the right mouse key!).

As an alternative, you can start in the SIMATIC Manager, as follows:

1. Open your CPU in the SIMATIC Manager.
2. Select the object **Connections** .
3. Double-click the object or select the menu command **Edit ► Open Object**.

Result: The connection table appears on the screen with all the connections configured for the selected CPU (local node).

As an alternative, you can also open the connection configuration from the graphic network view. Select the station or CPU of the station in NetPro. Select the **Insert ► New Connections** menu command.

New Connection

To configure a new connection, the stations and their CPs must be configured and networked in the S7 project. To create a new connection, follow the steps below:

1. Select the menu command **Insert ► New Connection**

Result: The following dialog appears on the screen.




Figure 4-4 Layout of the “New Connection” Dialog (Example of an ISO Transport Connection)

2. In the “Station” box, select the station to which you want to establish a connection. After you have selected your local station, all the remote partners in the S7 project and all their programmable modules (CPUs) are displayed for selection.
3. In the “Module” box, select the CPU in the station to which you want to establish a connection .
4. Select the connection type you want to use (for example ISO transport connection) in the “Type” box

If you confirm your entries with **Add**, the new connection is created and the “New Connection” remains open. This allows you to create further connections without needing to reopen the dialog box. At the same time, the connection list is updated.

When you click **OK**, the connection is entered in the list, the dialog is terminated and the display in the main dialog is updated.

If you click **Cancel**, the dialog is terminated and the connection is not entered in the list.

Connections to Non-S7 Stations using Substitute Objects

If you want to configure connections to devices or stations that are not S7 stations, select a station of the type “SIMATIC S5”, “PC/PG” or “Other Station” as the destination station.

By creating these stations in NetPro and networking them, you have already specified the node addresses (MAC or IP addresses) of the two stations. You must specify the TSAP (Transport Service Access Point) for the destination station.

Notice

Connections to non-S7 stations (for example SIMATIC S5) are generated as incompletely specified connections; in other words, the remote TSAP or port is empty. These connections must be specified in the Properties dialog.

4.3.2 Connections to Partners in Other Projects

There are two ways of creating connections to partners configured in other STEP 7 projects or with other tools outside the current STEP 7 project:

- Connections using substitute objects such as “SIMATIC S5”, “PC/PG” , “SIMATIC PC-Station” or “Other Station”.
This method is described in the section above.
- Unspecified connections

Unspecified Connections

Connections to an as yet unknown device (for example a diagnostic unit) are configured as “unspecified” connections. They can be specified later in the Properties dialog.

You can create an unspecified connection simply by selecting station “unspecified” for the connection partner when you create the connection. The unspecified connection can be used in two ways (explained below based on the example of an ISO-on-TCP connection (ISO transport and TCP connections are analogous):

- Declare readiness for communication – passive connection establishment

The connection establishment is then set to passive (see settings in the General tab).

The address setting for the ISO-on-TCP connection is then as follows:
The remote IP address is 0.0.0.0 and the remote TSAP is empty; in other words, they are not relevant for the CP. When the connection is established, any partner is accepted (partner = connection name that addresses the CP with the correct IP address and TSAP).

It is also possible to use a partial specification; in other words, communication is permitted with any partner that matches the specified TSAP.

- Connection to a specific station in any project

The address setting for the ISO-on-TCP connection is then as follows:
 You can specify the remote IP address and the port of any destination station.
 The destination station can be in the current STEP 7 project or in another project.

Use this method if you have not created a substitute object for the partner station, for example SIMATIC S5, in the current project.

The following table lists the possible options.

Table 4-2

Meaning for Connection Establishment	IP Address / MAC Address	TSAP / Port	Possible Connection Establishment
by any partner	empty	empty	passive
by any partner via specific TSAP	empty	specified	passive
to or by a specific partner	specified	specified	active / passive

The free UDP connection is another variant. With this type of connection, the address of the connection partner is left open during configuration. The communication nodes are identified by address information in the communication job in the user program.

For further information, refer to the sections dealing with specific connections.

Notice

The number of connections possible per Ethernet CP can be found in the product information LEERER MERKER supplied with the CP. If several CPs are installed in one station, the next CP is automatically selected if the limit is exceeded. The connections can be routed in the Properties dialog of the connection.

4.3.3 Further Functions

Toolbar

In the toolbar of the connection configuration dialog the following functions are available:

<p>Save</p> 	<p>To save the configured connection, select the Save function or click the save button.</p>
<p>Print</p> 	<p>You can print the entire connection table or individual sections of it by selecting the Print function or clicking the print button.</p> <p>The following print options are available:</p> <ul style="list-style-type: none"> • Overview of all connections (complete connection table) • Overview of the selected connections (selected area) • Detailed printout of all connections (details of all connections) • Detailed printout of the selected connections (details of the selected area)
<p>Change Connection Partners</p> 	<p>You assign a new partner station to the selected connection.</p> <p>Important! Remember that this also changes the partner ID on connections of the SEND/RECEIVE interface. You may need to adapt your user program.</p>
<p>Insert Connection</p> 	<p>You create a new entry in the connection table.</p>
<p>Download</p> 	<p>You download the connection table to the PLC. For more detailed information call up the integrated help function.</p>
<p>Help</p> 	<p>If you require help or more information, select the Help function or click the help button.</p> <p>The help button provides you with context-related help. Using the help function you call a help dialog familiar from other Windows applications.</p>

Print Function in the “Overview” Tab

An additional function for printing the configured connections and configuration status is available in the “Overview” tab.

4.3.4 Connections Without Assignment

Overview

This section explains the actions that can lead to a configured connection losing its assignment to the CP or being deleted.

Caution

Remember that in contrast to the S7 connections, the connections of the SEND/RECEIVE interface are assigned a CP-dependent ID. The actions below may require the ID to be modified so that the interface information in the user program must also be adapted.

Table 4-3 Actions That Can Cause Changes to Configured Connections

Action	Consequences for the Connections	How to Establish the Connection Again
The CP (module) is moved to a different location in the hardware configuration (drag and drop)	The connections are retained. The connection IDs are automatically updated.	<ol style="list-style-type: none"> 1. Adapt the module start address LADDR in the user program. 2. Download the connection configuration to the CP again.
The CP (module) is deleted in the hardware configuration. You receive the message "CP has n connections; the assignment will be lost in the connection table".	The connections remain without assignment to a CP in the connection table. In the "Overview" tab of the Properties dialog, the connections are identified with "!".	<p>Once you have placed a CP in the hardware configuration and networked it:</p> <ol style="list-style-type: none"> 1. Assign the CP in the connection properties dialog in the "Addresses" tab. or Reassign the connection using the menu option Edit ► Connection Partner.... 2. Adapt the connection ID in the user program. 3. Download the connection configuration to the CP again.
Deleting the SIMATIC S7 station.	All the connections to this station are deleted within the project.	Reconfigure the station and connections.

Table 4-3 Actions That Can Cause Changes to Configured Connections, continued

Action	Consequences for the Connections	How to Establish the Connection Again
Deleting a remote station.	The connections of the stations in the project to remote stations remain without assignment in the connection table. In the “Overview” tab of the Properties dialog, the connections are identified with “!”.	Reassign a remote station (or even a local station) using the menu option Edit ► Connection Partner...
Changing the subnet assignment of the CP.	The connections that were assigned via the CP remain without an assignment in the connection table. In the “Overview” tab of the Properties dialog, the connections are identified with “!”.	Reassign the connections using the menu option Edit ► Connection Partner... or in the “Addresses” tab of the properties dialog for the connection.

Display (Example)

The status of connections is displayed in the “Properties ISO Transport Connection” dialog in the “Overview” tab.




Figure 4-5 Status of the Connections in the “Overview” Tab (Example of ISO Transport Connections)

Notice

If a CP is replaced by a different CP, this must provide at least the same services and must be at least the same version.

4.4 Configuring ISO Transport Connections

Introduction

As well as the entry in the connection table, you can also modify special properties for each configured connection.

Here, you can change specific connection parameters that were entered as defaults during the new connection dialog.

Calling the Dialog

To call the dialog for special connection properties, follow the steps outlined below:

1. Select the required connection in the connection table.
2. Select the menu option **Edit ▶ Object Properties**

Result: The “Properties ISO Transport Connection” dialog appears.

Tabs

The following tabs are available for ISO transport connections:

- **General**
Displays the global parameters of the connection and the local name of the ISO transport connection.
- **Addresses**
Displays the local and remote address information.
- **Dynamics**
Displays the relevant timers and counters.
- **Options**
Here, you can select the following modes:
 - FETCH or WRITE
- **Overview**
This is an overview of all the configured ISO transport connections of the selected S7 station with their parameters and the status of the connection.
- **Status Information**
This tab displays the current status information for the connection (valid at the time the dialog is opened). This information corresponds to that displayed by NCM diagnostics.

4.4.1 Specifying the Local Connection Endpoint

General Tab

This tab in the properties dialog displays parameters for the connection and the local connection name of the ISO transport connection.

The local ID is identical to the ID in the NetPro connection table (STEP 7 connection configuration) and is shown here to illustrate the assignment.




Figure 4-6 Layout of the Properties Dialog for the "General" Tab (ISO Transport Connections)

Attributes	Description	Access
Connection Endpoint		
Local ID	Identical to the value from the connection list	Selectable
Name	Proposed name that can be changed by the user. With unspecified connections, use this box to identify the partner.	Modifiable
Via CP	If the station contains more than one CP of the same type connected to the same subnet, you can select the connection route. -> "Route" button see Section 4.8. If no CP is assigned (for example because the CP was previously deleted) "none" is displayed here.	Display only
Active Connection Establishment	The default setting is active. If the connection is unspecified, establishment is passive . ON: the connection is established actively. OFF: the connection is established by the partner.	Modifiable
Block Parameters		
ID	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection. The ID changes if the local ID is changed.	Display only
LADDR	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection.	Display only

“Active Connection Establishment” Option

With this option, you specify whether the connection is established by this S7 station. This is the default setting when the address of the partner is specified.

If you selected partner “unspecified” when you created the connection, the option is deselected as default. If you activate the option, you must also specify the address of the partner in the “Addresses” tab.

If you select FETCH or WRITE in the “Options” tab, the option is deselected (passive connection establishment) and cannot be selected.

4.4.2 Specifying ISO Transport Addresses

Address Parameters

An ISO transport connection is specified by the local and remote connection endpoint.

- Local addresses:
Local MAC address and local TSAP (Transport Service Access Point)
- Remote addresses:
Remote MAC address and remote TSAP




Figure 4-7 Sending and Receiving on **one** ISO Transport Connection

Notice

The TSAPs of an ISO transport connection must match as follows:

Remote TSAP (on Ethernet CP) = local TSAP (in destination station);

Local TSAP (on Ethernet CP) = remote TSAP (in destination station);

Addresses Tab

The addresses tab displays proposed values for the relevant local and remote address information. When connecting to non-S7 stations, you can set the TSAP addresses individually.




Figure 4-8 Layout of the “Addresses” Tab of the Properties Dialog with Default TSAPs

TSAP Format

ISO transport connections have a TSAP length of 1 to 32 bytes. When you are entering values, the current length is displayed automatically (visible display: 20 ASCII characters). Local and remote TSAPs can be input as hexadecimal values or as ASCII strings. If you make your entries in ASCII, the characters you enter are also displayed in hexadecimal format. If you make your entries in hexadecimal, printable characters are displayed in ASCII (8 hexadecimal values are visible). If you enter nonprintable characters, the ASCII display is gray (no further ASCII entries possible) and the nonprintable characters are displayed as periods.

Local and Remote TSAPs

Remote and local TSAPs can be identical since the connection is uniquely identified by the different MAC addresses. If you require more than one connection between two stations, the TSAPs must also be different.

Default TSAPs

When configuring the local and remote TSAPs, there is a default value “ISO-1” for the first connection between the two partners (can be changed). For a new connection between the two partners, the default value “ISO-2” is proposed. With a new connection to a new partner, the value ISO-1 is used again.

Addresses Tab – Unspecified ISO Transport Connection

If you select the partner type as “unspecified”, depending on your task, you can enter address information about the communication partner here. The options available to you are explained in detail in Section 4.3.1.

The Addresses tab shown here illustrates the situation in which the MAC address and the remote TSAP were not specified. If you do not make any further settings, this means that you are willing to accept a connection establishment request from any communication partner.




Figure 4-9 Layout of the “Addresses” Tab of the Properties Dialog for an Unspecified Connection

4.4.3 Specifying ISO Transport Dynamic Properties

Dynamics Tab

The Dynamics tab displays the relevant timers and counters of this connection. You can normally accept these default values.

If necessary, for example with connections to non-Simatic systems, you can set the timers and counters individually and influence the dynamic response of the connection.




Figure 4-10 Layout of the “Dynamics” Tab of the Properties Dialog

Attributes	Description	Access
Connection Establishment		
Retransmission Time	The retransmission time specifies the interval after which an unsuccessful connection establishment attempt can be triggered again (1–60 s, default 5 s) – if connection establishment is active – if connection establishment is passive (→ irrelevant)	Modifiable _____
Data Transfer		
Retransmission time	This parameter specifies the interval after which an unsuccessful transmission attempt can be triggered again (100–30000 ms, default 1000 ms).	Modifiable
Max. Count	Max. Count is the number of attempted transmissions including the first (1–100, default 5).	Modifiable

Attributes	Description	Access
Inactivity Time	The inactivity time specifies the interval after which the connection is terminated if no sign of life is received from the partner (6–180 s, default 30 s).	Modifiable
Window Time	The window time specifies the interval at which sign of life frames are sent. For SIMATIC NET CPs, the window time is set to 1/3 of the inactivity time (2–60 s, default 10 s). Sign of life frames are sent to check the connection when there is no data traffic.	Display only

Notice

Window Time and Inactivity Time

The partner responds to a sign of life frame with a frame. They are therefore sent to the partner at the intervals of the window time. To avoid unwanted connection termination, the inactivity time should be at least three times as long as the window time.

4.4.4 ISO Transport with the FETCH/WRITE Mode

Using FETCH PASSIVE / WRITE PASSIVE

If you select one of the FETCH PASSIVE or WRITE PASSIVE modes for the ISO transport connection, you can access the system areas on a SIMATIC S7 PLC from a SIMATIC S5 station or other non-S7 station.




Figure 4-11

The connection can then only be used for this mode; sending or receiving with the FCs AG_SEND/AG_LSEND or AG_RECV/AG_LRECV is then no longer possible.

The connection establishment is passive; in other words, only the partner station (SIMATIC S5 station or other non-S7 station) can establish the connection. The setting is made automatically in the "General" tab and cannot be changed.

- **FETCH**

If you select the FETCH mode, you allow direct read access to system memory on the SIMATIC S7 PLC. Such access can be, for example, from a SIMATIC S5 station or other station.

- **WRITE**

If you select the WRITE mode, you allow direct write access to system memory on the SIMATIC S7 PLC. Such access can be, for example, from a SIMATIC S5 station or other station.

Notice

If you select this configuration for an S7-300, remember that a connection resource (free connection for S7 Functions) of the S7-300 CPU is used! CPU connection resources are also used, for example, by S7-300 CPs, in the FMS mode or by PGs and OPs. For more detailed information about the maximum connection resources, refer to /12/ and /6/.

System Memory

You can access the following address areas in the system memory on the SIMATIC S7 PLC using FETCH or WRITE:

- Data blocks (DB)
(When accessing DBs, remember that the highest DB number is 255.)
- Bit memory (M, MB, MW, MD)
- Process image input table (I, IB, IW, ID)
- Process image output table (Q, QB, QW, QD)
- I/O area inputs (PIW, PID, PIB)
- I/O area outputs (PQW, PQD, PQB)
- Counters (C)
- Timers (T)

Links to Other Systems

The FETCH and WRITE modes supported on ISO transport connections and ISO-on-TCP or TCP connections can be used with any other device to access the S7 system memory areas.

To be able to use this type of access, for example for PC applications, you need to know the PDU structure of the jobs. The required S7 or S5 headers for request and response frames are 16 bytes long and their structure is described in the Appendix.

Messages in the Diagnostic Buffer

As a result of FETCH/WRITE access, negative acknowledgments from the S7 CPU are possible. This then leads to corresponding connection-oriented entries in the diagnostic buffer that you can read out with NCM Diagnostics (see Section 6.5).

4.4.5 Checking ISO Transport Connection Properties

Overview Tab

The Overview tab displays all previously configured ISO transport connections and their parameters for this station (information only).




Figure 4-12 Layout of the “Overview” Tab of the Properties Dialog

Parameter	Description
Local ID	This is the connection ID of the ISO transport connection
Conn. Name	Entered connection name identifying the ISO transport connection.
R/S	Rack/slot of the local CP via which the connection is established.
Remote address	Specifies the remote MAC address of the connection on the Ethernet subnet.
Local TSAP	Local transport service access point.
Partner TSAP	Remote transport service access point.
Status	The status displays the current configuration status of the connection. “Connections without assignment” are indicated by “No local CP/No remote CP” in the status column and a “!” character at the end of the “Local ID” (for example: 0002 A000!). Connections you are currently editing are also indicated by “!” at the end of the local ID.

You can set the column widths in the “Overview” tab individually.

Connection Overview with Multiple CPUs in an S7 Station

If you operate more than one CPU in your S7 station, you can click the button to extend the overview to the connections on all CPUs.

4.5 Configuring ISO-on-TCP Connections Properties

Introduction

As well as the entry the connection table, you can also modify specific connection parameters that were entered as defaults during the New connection dialog.

Calling the Dialog

To call the dialog for special connection properties, follow the steps outlined below:

1. Select the required connection in the connection table.
2. Select the menu option **Edit ▶ Object Properties**

Result: The “Properties ISO-on-TCP Connection” dialog appears.

Tabs

The following tabs are available for ISO-on-TCP connections:

- **General**
Displays the parameters of the connection and the local name of the ISO-on-TCP connection.
- **Addresses**
Displays the local and remote address information.
- **Options**
Here, you can select the following modes:
 - FETCH or WRITE
- **Overview**
This is an overview of all the configured ISO-on-TCP connections of the selected S7 station with their parameters and the status of the connection.
- **Status Information**
This tab displays the current status information for the connection (valid at the time the dialog is opened). This information corresponds to that displayed by NCM diagnostics.

4.5.1 Specifying the Local Connection Endpoint

General Tab

This tab in the properties dialog displays global parameters for the connection and the local connection name of the ISO-on-TCP connection.

The local ID is identical to the ID in the NetPro connection table (STEP 7 connection configuration) and is shown here to illustrate the assignment.




Figure 4-13 Layout of the “General” Tab in the Properties Dialog for ISO-on-TCP Connections

Parameter	Description	Access
Connection Endpoint		
Local ID	Identical to the value from the connection list	Selectable
Name	Proposed name plus suffix connection number that can be changed by the user (max. 24 characters).	Modifiable
Via CP	If the station contains more than one CP of the same type connected to the same subnet, you can select the connection route. → "Route" button see Section 4.8. If no CP is assigned (for example because the CP has been deleted) "none" is displayed here.	Display only
Active Connection Establishment	With this option, you specify whether the connection is established by this S7 station. This is the default setting when the address of the partner is specified. If you selected partner "unspecified" when you created the connection, the option is deselected as default. If you activate the option, you must also specify the address of the partner in the "Addresses" tab. If you select FETCH or WRITE in the "Options" tab, the option is deselected (passive connection establishment) and cannot be selected. ON: the connection is established actively. OFF: the connection is established by the partner.	Modifiable
Block Parameters		
ID	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection. The ID changes if the local ID is changed.	Display only
LADDR	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection.	Display only

4.5.2 Specifying ISO-on-TCP Addresses

Address Parameters

A connection is specified by the local and remote connection endpoint.

- Local addresses:
Local IP address and local TSAP
(Transport Service Access Point)
- Remote addresses:
Remote IP address and remote TSAP




Figure 4-14 Sending and Receiving on **one** ISO-on-TCP Connection

The address parameters are configured with NCM S7 and saved in the CP database. Modifications and extensions to the Industrial Ethernet network topology do not therefore have any effect on the CPU user program.

Notice

When you configure the Ethernet CP and the Ethernet destination station, the TSAPs of an ISO-on-TCP connection must cross match:
 Remote TSAP (in Ethernet CP) = local TSAP (in destination station)
 Local TSAP (in Ethernet CP) = remote TSAP (in destination station)

Addresses Tab

The addresses tab displays proposed values for the relevant local and remote address information. If necessary, you can set the TSAP addresses individually.




Figure 4-15 Layout of the “Addresses” Tab of the Properties Dialog with Default TSAPs for ISO-on-TCP Connections

TSAP Format

ISO-on-TCP connections have a TSAP length of 1 – 32 bytes. When you are entering values, the current length is displayed automatically (visible display: 20 ASCII characters). Local and remote TSAPs can be input as hexadecimal values or as ASCII strings. If you make your entries in ASCII, the characters you enter are also displayed in hexadecimal format. If you make your entries in hexadecimal, printable characters are displayed in ASCII (8 hexadecimal values are visible). If you enter nonprintable characters, the ASCII display is gray (no further ASCII entries possible) and the nonprintable characters are displayed as periods.

Local and Remote TSAPs

Remote and local TSAPs can be identical since the connection is uniquely identified by the different MAC addresses. If you require more than one connection between two stations, the TSAPs must also be different.

Default TSAPs

When configuring the local and remote TSAPs, there is a default value “TCP-1” for the first connection between the two partners (can be changed). For a new connection between the two partners, the default value “TCP-2” is proposed. With a new connection to a new partner, the value TCP-1 is used again.

Addresses Tab – Unspecified ISO-on-TCP Connection

If you select the partner type as “unspecified”, depending on your intentions, you can enter address information about the communication partner here. The options available to you are explained in detail in Section 4.3.1.

The Addresses tab shown here illustrates the situation in which the remote IP address and the remote TSAP were not specified. If you make no further entries, you are accepting connection establishment from any communication partner.




Figure 4-16 Layout of the “Addresses” Tab of the Properties Dialog for an Unspecified Connection

4.5.3 ISO-on-TCP with the FETCH/WRITE Mode

Using FETCH PASSIVE / WRITE PASSIVE

If you select one of the FETCH PASSIVE or WRITE PASSIVE modes for the ISO-on-TCP connection, you can access the system areas on a SIMATIC S7 PLC from a SIMATIC S5 station or other non-S7 station.




Figure 4-17

The connection can then only be used for this mode; sending or receiving with the FCs AG_SEND/AG_LSEND or AG_RECV/AG_LRECV is then no longer possible.

The connection establishment is passive; in other words, only the partner station (SIMATIC S5 station or other non-S7 station) can establish the connection. The setting is made automatically in the "General" tab and cannot be changed.

- **FETCH**

If you select the FETCH mode, you allow direct read access to system memory on the SIMATIC S7 PLC. Such access can be, for example, from a SIMATIC S5 station or other station.

- **WRITE**

If you select the WRITE mode, you allow direct write access to system memory on the SIMATIC S7 PLC. Such access can be, for example, from a SIMATIC S5 station or other station.

Notice

If you select this configuration for an S7-300, remember that a connection resource (free connection for S7 Functions) of the S7-300 CPU is used! CPU connection resources are also used, for example, by S7-300 CPs, in the FMS mode or by PGs and OPs. For more detailed information about the maximum connection resources, refer to /12/ and /6/.

System Memory

You can access the following address areas in the system memory on the SIMATIC S7 PLC using FETCH or WRITE:

- Data blocks (DB)
(When accessing DBs, remember that the highest DB number is 255.)
- Bit memory (M, MB, MW, MD)
- Process image input table (I, IB, IW, ID)
- Process image output table (Q, QB, QW, QD)
- I/O area inputs (PIW, PID, PIB)
- I/O area outputs (PQW, PQD, PQB)
- Counters (C)
- Timers (T)

Links to Other Systems

The FETCH and WRITE modes supported on ISO transport connections and ISO-on-TCP or TCP connections can be used with any other device to access the S7 system memory areas.

To be able to use this type of access, for example for PC applications, you need to know the PDU structure of the jobs. The required S7 or S5 headers for request and response frames are 16 bytes long and their structure is described in the Appendix.

Messages in the Diagnostic Buffer

As a result of FETCH/WRITE access, negative acknowledgments from the S7 CPU are possible. This then leads to corresponding connection-oriented entries in the diagnostic buffer that you can read out with NCM Diagnostics (see Section 6.5).

4.5.4 Checking ISO-on-TCP Connection Properties

Overview Tab

The overview shows all the configured ISO-on-TCP connections and their parameters (cannot be modified here).

You can adjust the width of the columns in the table.




Figure 4-18 Layout of the “Overview” Tab in the Properties Dialog for ISO-on-TCP Connections

Parameter	Description
Local ID	This is the connection ID of the ISO-on-TCP connection
Conn. Name	Entered connection name This identifies the ISO-on-TCP connection.
R/S	Rack/slot of the local CP via which the connection is established.
Remote Address	Specifies the remote IP address of the connection.
Local TSAP	Local transport service access point.
Remote TSAP	Remote transport service access point (8 characters default width).
Status	The status displays the current configuration status of the connection. “Connections without assignment” are indicated by “No local CP/No remote CP” in the status column and a “!” character at the end of the “Local ID” (for example: 0002 A000!). Connections you are currently editing are also indicated by “!” at the end of the local ID.

Connection Overview with Multiple CPUs in an S7 Station

If you operate more than one CPU in your S7 station, you can click the button to extend the overview to the connections on all CPUs.

4.6 Configuring TCP Connection Properties

Introduction

After the entry in the connection table, you can modify specific connection parameters for each configured connection that were given default values when you created the connection.

Calling the Dialog

To call the dialog for special connection properties, follow the steps outlined below:

1. Select the required connection in the connection table.
2. Select the menu option **Edit ▶ Object Properties**

Result: The “Properties – TCP Connection” dialog appears.

Tabs

The following tabs are available for TCP connections:

- **General**
Displays the parameters of the connection and the local name of the TCP connection.
- **Addresses**
Displays the local and remote address information.
- **Options**
Here, you can select the modes FETCH or WRITE.
- **Overview**
This is an overview of all the configured TCP connections of the selected S7 station with their parameters and the status of the connection.
- **Status Information**
This tab displays the current status information for the connection (valid at the time the dialog is opened). This information corresponds to that displayed by NCM diagnostics.

4.6.1 Specifying the Local Connection Endpoint

General Tab

This tab in the properties dialog displays parameters for the connection and the local connection name of the TCP connection.

The local ID is identical to the ID in the NetPro connection table (STEP 7 connection configuration) and is shown here to illustrate the assignment.




Figure 4-19 Layout of the "General" Tab in the Properties Dialog for TCP Connections

Attribute	Description	Access
Connection Endpoint		
Local ID	Identical to the value from the connection list	Selectable
Name	Proposed name plus suffix connection number that can be changed by the user (max. 24 characters).	Modifiable
Via CP	If the station contains more than one CP of the same type connected to the same subnet, you can select the connection route → "Route", see Section 4.8. If no CP is assigned (for example because the CP has been deleted) "none" is displayed here.	Display only
Active Connection Establishment	With this option, you specify whether the connection is established by this S7 station. This is the default setting when the address of the partner is specified. If you selected partner "unspecified" when you created the connection, the option is deselected as default. If you activate the option, you must also specify the address of the partner in the "Addresses" tab. ON: the connection is established actively. OFF: the connection is established by the partner.	Modifiable
"Use for FTP protocol" Option	Select this option to configure an FTP connection. Using an FTP connection, you can access an FTP server from the user program on the S7-CPU using special FCs. Requirement: The option can only be selected for an unspecified TCP connection. You can configure up to 10 FTP connections. Selecting the option has the following effects: <ul style="list-style-type: none"> • The TCP connection is now used as an FTP connection. • "Addresses" tab: The addresses are specified automatically (Port=21) • "Options" tab: The mode is set to FTP and cannot be changed. • The "Active connection establishment" option is irrelevant and cannot be set. 	Can be selected for an unspecified TCP connection
Block Parameters		
ID	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection. The ID changes if the local ID is changed.	Display only
LADDR	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection.	Display only

4.6.2 Specifying TCP Addresses

Address Parameters and Connection Types

With TCP, the communication partners are addressed by the local and remote endpoints as follows:

- Local addresses:
Local IP address and local port
- Remote addresses:
Remote IP address and remote port




Figure 4-20 Sending and Receiving on One TCP Connection

Depending on the required connection type, the remote address parameters are either specified or left open during configuration.

- Specified TCP connection
You specified a destination station when you created the connection.
- Unspecified TCP connection
You entered “unspecified” for the connection partner when you created the connection.

Addresses Tab – Specified TCP Connection

The addresses tab displays proposed values for the relevant local and remote address information. You can change the port settings individually.




Figure 4-21 Layout of the Properties Dialog in the “Addresses” tab with DEFAULT Ports for TCP Connections

Ports

The ports or port addresses define the access point to the user program within the station / CPU. They must be unique within the station / CPU!

The following table shows the range of values:

Table 4-4

Application / Note	Port Addresses
Fixed, must not be used!	0
Assigned as default, should not be used (well-known ports)	1 to 1024
Range used by NCM in which a free port address is searched for and assigned. You can set any port address within this range.	from 2000 to 5000
Port addresses higher than 5000 are used by the system! Note: If you want to use this port address, please contact your system administrator.	from 5000...65535

Addresses Tab – Unspecified TCP Connection

If you select the partner type as “unspecified”, depending on your intentions, you can enter address information about the communication partner here. The options available to you are explained in detail in Section 4.3.1.

The Addresses tab shown here illustrates the situation in which the remote port but not the IP address was specified. If you make no further entries, you are accepting connection establishment with any communication partner that uses the specified port.




Figure 4-22

4.6.3 TCP with the FETCH/WRITE Mode

Using FETCH PASSIVE / WRITE PASSIVE

If you select one of the FETCH PASSIVE or WRITE PASSIVE modes for the TCP connection, you can access the system areas on a SIMATIC S7 PLC from a SIMATIC S5 station or other non-S7 station.




Figure 4-23

The connection can then only be used for this mode; sending or receiving with the FCs AG_SEND/AG_LSEND or AG_RECV/AG_LRECV is then no longer possible.

The connection establishment is passive; in other words, only the partner station (SIMATIC S5 station or other non-S7 station) can establish the connection. The setting is made automatically in the “General” tab and cannot be changed.

- **FETCH**

If you select the FETCH mode, you allow direct read access to system memory on the SIMATIC S7 PLC. Such access can be, for example, from a SIMATIC S5 station or other station.

- **WRITE**

If you select the WRITE mode, you allow direct write access to system memory on the SIMATIC S7 PLC. Such access can be, for example, from a SIMATIC S5 station or other station.

Notice

If you select this configuration for an S7-300, remember that a connection resource (free connection for S7 Functions) of the S7-300 CPU is used! CPU connection resources are also used, for example, by S7-300 CPs, in the FMS mode or by PGs and OPs. For more detailed information about the maximum connection resources, refer to /12/ and /6/.

System Memory

You can access the following address areas in the system memory on the SIMATIC S7 PLC using FETCH or WRITE:

- Data blocks (DB)
(When accessing DBs, remember that the highest DB number is 255.)
- Bit memory (M, MB, MW, MD)
- Process image input table (I, IB, IW, ID)
- Process image output table (Q, QB, QW, QD)
- I/O area inputs (PIW, PID, PIB)
- I/O area outputs (PQW, PQD, PQB)
- Counters (C)
- Timers (T)

Links to Other Systems

The FETCH and WRITE modes supported on ISO transport connections and ISO-on-TCP or TCP connections can be used with any other device to access the S7 system memory areas.

To be able to use this type of access, for example for PC applications, you need to know the PDU structure of the jobs. The required S7 or S5 headers for request and response frames are 16 bytes long and their structure is described in the Appendix.

Messages in the Diagnostic Buffer

As a result of FETCH/WRITE access, negative acknowledgments from the S7 CPU are possible. This then leads to corresponding connection-oriented entries in the diagnostic buffer that you can read out with NCM Diagnostics (see Section 6.5).

4.6.4 Checking TCP Connection Properties

Overview Tab

The overview shows all the previously configured TCP connections and their parameters (cannot be modified here).

You can adjust the width of the columns in the table.




Figure 4-24 Layout of the “Overview” Tab in the Properties Dialog for TCP Connections

Parameter	Description
Local ID	This is the connection ID of the TCP connection (STEP 7 connection configuration; DWORD)
Conn. Name	Entered connection name It identifies the TCP connection (8 character double width).
R/S	Rack/slot of the local CP via which the connection is established.
Remote address	Specifies the remote IP address of the connection.
Local port	Local port (8 characters default length)
Remote port	Remote port (8 characters default width)
Status	The status displays the current configuration status of the connection. “Connections without assignment” are indicated by “ No local CP/No remote CP ” in the status column and a “!” character at the end of the “Local ID” (for example: 0002 A000!). Connections you are currently editing are also indicated by “!” at the end of the local ID.

Connection Overview with Multiple CPUs in an S7 Station

If you operate more than one CPU in your S7 station, you can click the button to extend the overview to the connections on all CPUs.

4.7 Configuring UDP Connection Properties

Introduction

After the entry in the connection table, you can modify specific connection parameters for each configured connection that were given default values when you created the connection.

Calling the Dialog

To call the dialog for special connection properties, follow the steps outlined below:

1. Select the required connection in the connection table.
2. Select the menu option **Edit ► Object Properties**

Result The “Properties – UDP Connections“ dialog appears.

Tabs

The following tabs are available for UDP connections:

- **General**
Displays the parameters of the connection and the local name of the UDP connection.
- **Addresses**
Displays the local and remote address information.
- **Overview**
Overview of all configured UDP connections of the selected S7 station with corresponding parameters and the status of the connection.
- **Status Information**
This tab displays the current status information for the connection (valid at the time the dialog is opened). This information corresponds to that displayed by NCM diagnostics.

4.7.1 Specifying the Local Connection Endpoint

General Tab

This tab of the Properties dialog displays the parameters of the connection and a local connection name for the UDP connection.

The local ID is identical to the ID in the NetPro connection table (STEP 7 connection configuration) and is shown here to illustrate the assignment.




Figure 4-25 Layout of the “General” Tab in the Properties Dialog for UDP Connections

Attributes	Description	Access
Connection Endpoint		
Local ID	Identical to the value from the connection list	Selectable
Name	Proposed name plus suffix connection number that can be changed by the user (max. 24 characters).	Modifiable
Via CP	If the station contains more than one CP of the same type connected to the same subnet, you can select the connection route -> "Route", see Section 4.8. If no CP is assigned (for example because the CP has been deleted) "none" is displayed here.	Display only
Block Parameters		
ID	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection. The ID changes if the local ID is changed.	Display only
LADDR	This value must be entered as a block call parameter ID for calling the FC in the user program to identify the connection.	Display only

4.7.2 Specifying UDP Addresses

Address Parameters and Connection Types

With UDP, the communication partners are addressed using the local and remote endpoint, as follows.

- Local addresses:
Local IP address and local port
- Remote addresses:
Remote IP address and remote port

Note

The term “connection” is also used here for UDP. Reason: during configuration (just as in TCP) the communication partners are assigned to each other and therefore logically “connected”. In actual fact, with UDP there is no explicit connection establishment between communication partners.




Figure 4-26 Sending and Receiving on One UDP Connection

Depending on the required connection type, the remote address parameters are either specified or left open during configuration.

- Specified UDP connection
 You specified a destination station when you created the connection.
 Configuring broadcast or multicast provides you with a further option (see Section 4.7.3 below).
- Unspecified UDP connection
 You entered “unspecified” for the connection partner when you created the connection.
- Connection to all Broadcast Nodes
 If you select the connection type “Connection to all broadcast nodes”, you specify that UDP frames are sent to all obtainable broadcast nodes.

Addresses Tab – Specified UDP Connections

The addresses tab displays proposed values for the relevant local and remote address information. You can make the settings for the ports individually.




Figure 4-27 Layout of the Properties Dialog in the “Addresses” tab with DEFAULT Ports for UDP Connections

Ports

The ports or port addresses define the access point to the user program within the station / CPU. They must be unique within the station / CPU!

The following table shows the range of values:

Table 4-5

Application / Note	Port Addresses
Fixed, must not be used!	0
Assigned as default, should not be used (well-known ports)	1 to 1024
Range used by NCM in which a free port address is searched for and assigned.	2000... onwards

Addresses Tab – Unspecified UDP Connection

An unspecified UDP connection can be used in two ways:

- Free UDP Connection

To configure a free UDP connection, select the “Address assignment in block” check box. The input boxes for the remote IP address and the remote port are then deactivated since the destination addresses are now specified by the user program.

- Connection to a remote station in a different project

You can specify the remote IP address and the port for any destination station. The destination station can be in the current or a different STEP 7 project.

Please note:

Since no connection is actually established with UDP (datagram service), communication on the configured UDP connection is only possible when the partner addresses (IP address and port) are specified.




Figure 4-28 Layout of the Properties Dialog in the “Addresses” Tab for the “Free UDP Connection” Mode

4.7.3 UDP with Broadcast and Multicast

Application

When you select the connection partner, you have the following two extra options on UDP connections:

- Connection to all Broadcast Nodes

If you select “all broadcast nodes” as the connection partner, you specify that UDP frames are sent to all obtainable broadcast nodes.

Notice

When using broadcast, you can only send with S7 CPs; reception is not possible (see below)!

- Connection to all Multicast Nodes

If you select “all multicast nodes” as the partner, you specify that UDP frames are sent to all nodes of a multicast group and that multicast frames can be received.

Multicast is a special, configurable connection option that is supported by Industrial Ethernet CPs only on UDP connections.

The frames are sent without acknowledgment because the UDP protocol has no provision for acknowledgments. This is designed to avoid floods of data resulting from the acknowledgments. If, for example, frames are sent to 100 partners, 100 acknowledgments (1 per partner) will arrive at the same time. The sending module would not be able to evaluate such a flurry of data.

When to Use Multicast instead of Broadcast

To allow the simultaneous transmission of a frame to a number of partners, the connection option Multicast for UDP connections was introduced.

In contrast to the broadcast connection option, it is also possible to receive frames sent to several nodes in the multicast group on this connection type.

By specifying a particular group of recipients (multicast group), load on recipients for which the message is not intended is prevented. Multicast therefore represents a better solution than broadcast when frames are sent to groups of partner stations.

Why Does an S7 CP Prevent Reception on Broadcast Connections?

It is often necessary for one station to send frames to a number of partner stations. It is important that the frames are sent at the same time and arrive at practically the same time. Sending and receiving broadcast frames is always required. A broadcast message is received by all nodes in the network.

A typical application is the sending of broadcast frames to find a MAC address for an IP address (ARP request).

For this reason, a communications module must accept broadcast frames and evaluate them in its software. The major disadvantage of this is that network performance sinks significantly if there are too many broadcast frames because each individual module needs to process all the broadcast frames to find out whether the frames were intended for it.

To avoid these disadvantages, S7 CPs handle broadcast as follows:

- Following reception, the broadcast frames are filtered out with high priority by all Ethernet CPs. This means that frames that cannot be interpreted are discarded immediately. Only frames that can be interpreted, for example an ARP request, are passed on over the LAN controller and evaluated. This prevents a negative influence on the other connections by broadcast frames.
- For the application, this means that the S7 CP cannot receive broadcast frames intended for the transfer of user data. It is, however, possible for the module to send broadcast frames within the network.

Addresses Tab – Connection to all Broadcast Nodes

If you select “all broadcast nodes” as the connection partner, you specify that UDP frames are sent to all obtainable broadcast nodes.

In the “Addresses” tab, a valid broadcast address in the network is proposed for the partner under the IP address (IP).

You must enter a PORT address suitable for all partners you want to reach under PORT.




Figure 4-29 Layout of the Properties Dialog “Addresses” Tab for the “Broadcast” Mode


Addresses Tab – Connection to all Multicast Nodes

By selecting “all multicast nodes” as the connection partner, you specify that

- sent UDP frames are delivered to all multicast nodes of the multicast group;
- the local device receives multicast frames in the specified multicast group.

In the “Addresses” tab, a valid multicast address in the network is proposed for the partner under the IP address (IP). When using multicast, the partner is always a group of receivers (multicast group).

You must enter a PORT address suitable for all partners you want to reach under PORT.



IP addresses from 224.0.0.0 to 239.255.255.255 can be used for IP multicast.

Since the IP addresses up to 224.0.0.255 are reserved for special purposes, we recommend that you use IP addresses starting at 224.0.1.0 (default) for IP multicast.

4.7.4 Checking the Properties of a UDP Connection

Overview Tab

At the overview level, all the configured UDP connections and their parameters in this station are displayed (cannot be modified).

You can adjust the width of the columns in the table.




Figure 4-30 Layout of the “Overview” Tab in the Properties Dialog for UDP Connections

Parameter	Description
Local ID	This is the connection ID of the UDP connection (STEP 7 connection configuration; DWORD)
Conn. Name	Entered connection name This identifies the UDP connection (8 characters default length).
R/S	Rack/slot of the local CP via which the connection is established.
Partner address	Specifies the remote IP address of the connection.
Local port	Local port (8 characters default length)
Remote port	Remote port (8 characters default width)
Status	The status displays the current configuration status of the connection. “Connections without assignment” are indicated by “ No local CP/No remote CP ” in the status column and a “!” character at the end of the “Local ID” (for example: 0002 A000!). Connections you are currently editing are also indicated by “!” at the end of the local ID.

Connection Overview with Multiple CPUs in an S7 Station

If you operate more than one CPU in your S7 station, you can click the button to extend the overview to the connections on all CPUs.

4.7.5 Free UDP Connection

Program-Controlled Addressing

A free UDP connection allows program-controlled addressing of the communication partner. Communication between two nodes on Industrial Ethernet has the following properties:

- Data transfer is bi-directional; in other words it is possible to send and receive on the UDP connection at the same time.
- The local node is specified in the configuration. The remote node is entered in the job header of the job buffer by the user program when it calls AG_SEND. This allows any node on Ethernet/LAN/WAN to be reached.
- The IP address and the port of the sender can be read from the job header of AG_RECV.




Figure 4-31 Sending and Receiving on an Unspecified UDP Connection with Programmed Addressing

Amounts of Data

Refer to the product information /1/ accompanying the Ethernet CP for the number of UDP connections supported by the Ethernet CP. The number of connections per station can be increased by adding more CPs.


Up to 2042 bytes of user data can be transferred per job buffer. The job header uses an additional 6 bytes.

4.8 Routing to Distribute Load

Routing to Distribute Load

If more than one CP of the same type exists in a station and is connected to the same subnet, the route can be selected.

Click the “Route” button in the “General” tab to display the route dialog:



If you have configured a load distribution on two or more Ethernet CPs at the local or remote end, you can assign the connection to the required route via the CP.

Parameter	Description
Via CP / Local	<p>If more than one Ethernet CP exists in the station via which connections operated you can select route here.</p> <p>The CPs are only displayed for selection if they are networked.</p> <p>If no CP is assigned (for example because the CP was deleted previously) “(None)” is displayed here.</p> <p>If there is only one CP plugged into the station, no selection is possible.</p>
Via CP / Partner (remote)	<p>Depending on the local selection, the possible remote CPs are displayed. All the CPs connected to the same subnet (networked) and the local CP can be selected.</p> <p>Alternatives are only available when a connection is established to a remote station configured in the same project and the remote station has two or more CPs.</p> <p>If there is no CP assigned on the partner (for example because the CP was deleted previously) “None” is displayed here.</p> <p>If there is only one CP in the remote station, no selection is possible.</p> <p>If the partner is an “other station” or SIMATIC S5 PLC, one or more attachments are displayed for selection depending on the configuration and networking of the station.</p>



Programming FCs (Functions) for S7 Ethernet CPs

5

“Off-the-peg” blocks form the interface to some of the communications services available with the Ethernet CPs. This chapter includes a detailed description of these blocks.

The description of each FC includes the following sections that may be extended by specific information:

- Meaning
- Call Interface
- How the Block Works
- Explanation of the Formal Parameters
- Return Codes

This chapter provides you with information over and above the general information available in the online help for the FCs when programming in STEP 7.



You will find further information in the following sources:

- The communication FBs (BSEND, BRCV, PUT, GET, USEND, URCV, C_CNTRL) for programming S7 communication are described in the STEP 7 Documentation /8/.

Sample configurations and programs are available for the SEND/RECEIVE interface described here:

- In the sample project PROJECT_ETHERNET that you can start immediately after installing NCM S7; for a description, refer to the Primer /3/.
- On the Internet as downloadable sample projects; refer to the information in Appendix C “Support and Training”.



The Quick Start CD that can be ordered separately is a treasure-trove of sample programs and configurations.

You can order this directly on the Internet at:

<http://www.ad.siemens.de/csi/net> Entry ID: 574211

5.1 General Notes on FCs

Supplied in a Block Library

The functions (blocks of the type FC) described here are supplied with the standard STEP 7 package.

The following list shows the numbers of the FCs as they are shipped. You can change these numbers. You will also find the following information on the block library in the SIMATIC Manager:

- SIMATIC_NET_CP

These blocks are available when you install the NCM S7 for Industrial Ethernet option (default setting in STEP 7 Setup). Please note that you must use different FCs for the S7-300 and S7-400 (separate libraries).

Communication Service	FC Type ¹⁾		SIMATIC Manager Library		Described in
			SIMATIC_NET_CP		
			CP 300	CP 400	
SEND/RECEIVE (S5-compatible communication)	FC5	AG_SEND	x	x	Section 5.3
	FC6	AG_RECV	x	x	
	FC7	AG_LOCK	x	x	
	FC8	AG_UNLOCK	x	x	
	FC50	AG_LSEND		x	
	FC60	AG_LRECV		x	
S7 communication	FB12	BSEND	x		STEP 7 documentation /8/
	FB13	BRCV	x		
	FB15	PUT	x		
	FB14	GET	x		
	FB8	USEND	x		
	FB9	URCV	x		
	FC62	C_CNTRL	x		
FTP (IT-CPs)	FC40	FTP_CONNECT	x	x	SIMATIC NET IT-CP, Instructions /4/
	FC41	FTP_STORE	x	x	
	FC42	FTP_RETRIEVE	x	x	
	FC43	FTP_DELETE	x	x	
	FC44	FTP_QUIT	x	x	
PROFINet	FB88	PN_InOut	x		CP 343-1 PN Manual /1/

¹⁾ Note:

The following descriptions also include information on differences between the various block versions. Please take note of the version identifiers of the blocks you

are using.

The SIMATIC Manager block libraries installed with STEP 7 / NCM S7 contain the block versions that were current at the time of the STEP 7 release.

Note

We recommend that you always use the latest block versions for all module types.

You will find information on the current block versions and the current blocks to download from the Internet in our customer support.

<http://www4.ad.siemens.de/view/cs/en/8797900>

Entry ID: 8797900

With the older module types, this recommendation assumes that you are using the latest firmware for the particular block type.

Notice

At various points in this chapter, you will find information on the different CP versions. These passages are highlighted with the following symbol:



Newer CP types are CPs / module types with the following versions or higher:

CP 343-1

6GK 7343-1EX11-0XE0 version 1 or higher / firmware version V2.0 or higher

CP 343-1PN

6GK 7343-1HX00-0XE0 version 1 or higher / firmware version V2.0 or higher

CP 343-1 IT

6GK 7343-1GX00-0XE0 version 1 or higher / firmware version V2.0 or higher

FCs and Module Replacement (Spares)

Module replacement in this sense means the replacement of a module with another module that may be a more recent version.

Notice

Please remember that if you replace a module, you must only use the blocks permitted for the configured CP type in the user program.

This means:

- If you replace the module without adapting the configuration data to the possibly newer module type, you do not need to make any changes to the blocks used.
- If you replace the module and you do adapt the configuration data to the newer module type, you must use the block versions approved for this module type.

We recommend that you always use the latest block versions for all module types. With the older module types, this recommendation assumes that you are using the latest firmware for the particular block type.

You will find more information on replacing blocks in our Customer Support on the Internet.

The manuals /1/ contain information on the compatibility of the S7 CPs and the corresponding blocks (FCs / FBs).

5.2 Setting Parameters for FC Calls

Before describing the FCs in detail, a few general comments on calling and setting parameters for FCs will be useful in this point.

It is possible to make the following general statements about the following parameter groups that occur in all FCs:

- Parameters for CP and connection assignment (input parameters)
- Parameters for specifying a CPU data area (input parameters)
- Status information (output parameters)

Calling Communication Blocks for an S7-300

Caution

The communication blocks for S7-300 (SIMATIC NET block libraries for S7-300 in STEP 7) must not be called in more than one priority class! If, for example, you call a communication block in OB1 and in OB35, block execution could be interrupted by the higher-priority OB.

If you call blocks in more than one OB, you must write your program so that a communication block that is currently executing cannot be interrupted by another communication block (for example by disabling/enabling SFC interrupts).

5.2.1 Parameters for CP and Connection Assignment (input parameters)

When you call an FC, you transfer the module start address of the Ethernet CP in the CPLADDR or LADDR parameter. The module start address of the Ethernet CP can be found in the properties dialog of the CP in the "Address/Input" tab (can be selected in the SIMATIC Manager or in HW Config).

With connection-oriented jobs, you must also reference the connection to be used by its connection ID. You will find this in the properties dialog of the connection under "Block parameters" (refer to the information in NetPro).

Setting Block Parameters Automatically ¹⁾

To ensure correct parameter settings for the block calls, The LAD/STL/FBD editor in STEP 7 provides you with the option of accepting all the relevant parameters from the hardware configuration (HW Config) and from the connection configuration.

When assigning the parameters for the block in the user program, follow the steps outlined below:

1. Select the block call and its block parameters;
2. Right-click and select the menu command “**Connections...**”.
3. Depending on the block type, you can now select the connection and/or module intended for the block from a list.
4. Confirm your selection; as far as possible, the available parameter values are entered in the block call.

Response to Incorrect Addresses

If the S7 CPU cannot communicate with the Ethernet CP using the specified module base address, the errors described below occur.

Cause	Reaction / Code
No module can be addressed or identified at the specified CP address.	The CPU remains in the stop with system error state; in this case, evaluate the diagnostic buffer of the CPU.
The CP address points to a different module type.	Possible error code in the STATUS parameter of the communication block: 8184H System error 80B0H Module does not recognize data record. 80C0H Data record cannot be read. 80C3H Resources occupied (memory). 80D2H Logical base address wrong.

Notice

If you inadvertently address not a CP but another module type, errors occur that cannot be indicated by the error messages of the FCs themselves.

1). This function is possible only with the block library ..V50 SP3 or later.

5.2.2 Parameters for Specifying a CPU Data Area (input parameters)

Specifying the Data Area on the CPU

When you call an FC, you transfer the address and length of the data area on the CPU in which the user data are available or will be stored or which can contain further parameter information.

The ANY pointer data type is used to address this area. For more detailed information on this data type, refer to the STEP 7 online help under the topic "Format of the Parameter Type ANY". You will also find a detailed description of the ANY point in /20/.

5.2.3 Status Information (output parameters)

For status evaluation, the following parameters must be evaluated in the user program:

- DONE or NDR
These parameters (DONE with send jobs and NDR with receive jobs) signal (successful) completion of the job.
- ERROR
This indicates that the job could not be executed error-free.
- STATUS
This parameter supplies detailed information about the execution of the job. Status codes can be returned during execution of the job (DONE=0 and ERROR=0).

Evaluating Status Codes

Remember that the status codes DONE, NDR, ERROR, STATUS are updated at each block call.

Status Codes during CP Startup

With a complete restart or restart of the Ethernet CP (after activating a switch on the module), the output parameters of the FC are reset as follows:

- DONE = 0
- NDR = 0
- ERROR = 0
- STATUS = 8180_H for AG_RECV / AG_LRECV or 8181_H for AG_SEND /AG_LSEND

5.3 FCs for Configured Connections

Overview

The following functions (FCs) are available for transferring data over configured connections:

FC	Can be used with ¹⁾		Meaning
	S7 – 300	S7 – 400	
AG_SEND (FC5)	x	x	for sending data
AG_RECV (FC6)	x	x	for receiving data
AG_LSEND (FC50)		x	for sending data
AG_LRECV (FC60)		x	for receiving data

¹⁾ Notes on the FCs in FCs for an S7-300 and S7-400

- S7-300:

With older versions of the Ethernet CPs, the data length per job is restricted to <=240 bytes (applies up to block version V3.0 of AG_SEND / AG_RECV); with later versions, longer data records (up to 8092 bytes) can be transferred with FCs AG_LSEND or AG_LRECV.



With the latest versions of the Ethernet CPs, only FCs AG_SEND and AG_RECV are used; due to a new and more efficient internal protocol, the data up to 8092 bytes can be transferred.

- S7-400:


With FCs AG_SEND / AG_RECV the data length per job is restricted to <=240 bytes.

Longer data records (up to 8092 bytes) can be transferred with FCs AG_LSEND or AG_LRECV.

Please read the manual /3/ of the CP you are using to find out which data area is supported. You will find an overview of the versions of the FCs/FBs in the documentation and block history.

Application

The following diagram illustrates the use of the FCs described here for bi-directional data transfer on **one** configured connection.



Note

Unless specifically stated otherwise, the information on this and the following pages refers to AG_SEND / AG_LSEND or AG_RECV / AG_LRECV.

Specifying the Data Area on the CPU

When you call an FC, you transfer the address and length of the data area in the CPU. Remember, that the maximum length of the data area depends on the block type and block version being used.

- AG_SEND and AG_RECV

Up to version V3.0 of these blocks, a maximum of 240 bytes could be sent or received. The current block versions allow a data area of up to 8192 bytes for an S7-300. With an S7-400, the FCs AG_LSEND / AG_LRECV must still be used for larger data areas.

- AG_LSEND / AG_LRECV

Using the CPs of the S7-400 and with earlier versions of the S7-300, larger data areas can only be transferred with the FCs AG_LSEND or AG_LRECV. Please check the length of the data area in the product information.

The following table shows the limit values of the various connection types.

Table 5-1

FC	ISO Transport	ISO-on-TCP	TCP	UDP
AG_LSEND (S7-400) AG_SEND (S7-300)	8192 bytes	8192 bytes	8192 bytes	2048 bytes
AG_LRECV (S7-400) AG_RECV (S7-300)	8192 bytes	8192 bytes	8192 bytes	2048 bytes

Note

For information on the length of the data area you can transfer with older versions of the Ethernet CPs, refer to the product information bulletin / manual of the Ethernet CP you are using /1/.

Working without the Job Header

On specified connections, the address and job parameters are specified by the connection configuration. The user program only provides the user data in the UDP data area when sending with AG_SEND / AG_LSEND or receives the data with AG_RECV / AG_LRECV.

Application with Job Header

Free UDP connections require a job header in the user data area.

The following diagram illustrates the structure of the job buffer and the meaning and location of the parameters in the job header.




Figure 5-1 Sending and Receiving on a Free UDP Connection with Programmed Addresses

- In the picture (entries in hexadecimal) the following IP address is assumed: 142.11.40.35 (example only);
- For the port address 1003, the following would be entered: for low byte: EB_H; for high byte: 03_H.
- The user data area can be up to 2048 bytes long. Up to 2042 bytes of user data can be transferred. 6 bytes are reserved for the job header.

Please note that the data length specified in the block call (LEN parameter) must include the header and the user data!

5.3.1 FC5 AG_SEND / FC50 AG_LSEND

Meaning of the Block

The FCs AG_SEND / AG_LSEND pass data to the Ethernet CP for transfer over a configured connection.

The data area specified can be a process image area, a bit memory area or a data block area.


Error-free execution of the function is indicated when the entire user data area could be sent on Ethernet.

Note:

Unless otherwise stated, all the following information applies to both the FCs AG_SEND and AG_LSEND.

Call

Call interface in LAD representation



Example in STL representation

STL	Explanation
<code>call fc 5</code>	
<code>ACT := M 10.0</code>	//AG_SEND / AG_LSEND block call
<code>ID := MW 12</code>	//Job triggered by memory bit
<code>LADDR := W#16#0100</code>	//Connection ID acc. to configuration
<code>SEND := P#db99.dbx10.0 byte 240,</code>	//=LADDR 256 dec. in hardware configuration
<code>LEN := MW 14</code>	//Buffer with send data
<code>DONE := M 10.1</code>	//Length for send data
<code>ERROR := M 10.2</code>	//Execution code
<code>STATUS := MW 16</code>	//Error code
	//Status code

Notice

Please note the following special feature on TCP connections:

With the S7 CPs for S7-400, you must use FC AG_LSEND on TCP connections!




With the latest S7 CPs for S7-300, you must also use FC AG_SEND for TCP connections.

How the Block Works

The following diagram illustrates the normal sequence of data transmission triggered in the user program using AG_SEND.

Each AG_SEND job in the user program is acknowledged by the Ethernet CP with an entry in the output parameters DONE, ERROR and STATUS.



Legend:

1) Parameter transfer DONE, ERROR, STATUS

The status code is updated at each block call. To update the status return code without a new send job, the parameter ACT=0 must be set.

Explanation of the Formal Parameters

The following table explains all the formal parameters for the AG_SEND /AG_LSEND functions.

Parameter	Declaration	Type	Possible Values	Remarks
ACT	INPUT	BOOL	0,1	If ACT=1, LEN bytes are sent from the data area specified with the SEND parameter. If ACT=0, the status codes DONE, ERROR and STATUS are updated.
ID	INPUT	INT	1,2 to 64 (S7-400) 1,2 to 16 (S7-300)	The connection number of the connection is specified in the parameter ID (See configuration Section 4.3.1).
LADDR	INPUT	WORD		Module start address When you configure the CP with STEP 7 hardware configuration, the module base address is displayed in the configuration table. Specify this address here.
SEND	INPUT	ANY		Specifies address and length The address of the data area refers to one of the following: – Process image area – Bit memory – Data block area
LEN	INPUT	INT	On ISO Transport and ISO-on-TCP / TCP: 1,2, to 32767 (or up to “length specified for SEND parameter”) On UDP: 1,2, to 2048 (or up to “length specified for SEND parameter”)	Number of bytes to be sent from the data area with this job. The possible values range from 1 to length specified for the SEND parameter. <ul style="list-style-type: none"> Note the block type: <ul style="list-style-type: none"> S7-300 With older versions of FC AG_SEND (up to V3.0), the data area is always restricted to a maximum of 240 bytes. The current versions allow up to 8192 bytes. S7-400 With FC AG_SEND, the data area is restricted to a maximum of 240 bytes. Note on the S7-400: Data transfer may be restricted to LEN<=240 bytes with older versions of the CP firmware! For further information, see /1/ Improved performance with shorter data records: Transfer of data records up to 240 bytes results in better performance regardless of the block type used.

Parameter	Declaration	Type	Possible Values	Remarks
DONE	OUTPUT	BOOL	0: Job active 1: done	This parameter indicates whether or not the job was completed without errors. As long as DONE = 0, no further job can be triggered. DONE is set to 0 by the CP when it accepts a new job. For the meaning of this parameter in conjunction with the ERROR and STATUS parameters, refer to the following table.
ERROR	OUTPUT	BOOL	0: – 1: error	Error code For the meaning of this parameter in conjunction with the DONE and STATUS parameters, refer to the following table.
STATUS	OUTPUT	WORD	see following table	Status code The following table shows the condition codes formed by the DONE and ERROR parameters.

Return Codes

The following table shows the meaning of the information provided by DONE, ERROR and STATUS that must be evaluated by the user program.

Note

For entries coded with 8Fxx_H in STATUS, refer to the information in the STEP 7 Standard and System Functions reference manual. The chapter describing error evaluation with the RET_VAL output parameter contains detailed information.

To find out which SFCs are used and are relevant for error evaluation, display the properties dialog of the FC described here in the "Calls" tab.

Table 5-2 AG_SEND / AG_LSEND Codes

DONE	ERROR	STATUS	Meaning
1	0	0000 _H	Job completed without error.
0	0	0000 _H	No job being executed.
0	0	8181 _H	Job active.
0	1	7000 _H	This code is possible only with the S7-300: the FC was called with ACT=0; the job has not yet been processed.
0	1	8183 _H	No configuration or the ISO/TCP service has not yet started on the Ethernet CP.
0	1	8184 _H	System error.
0	1	8185 _H	LEN parameter longer than SEND source area.
0	1	8186 _H	ID parameter invalid. ID!=1,2 to 64.

Table 5-2 AG_SEND / AG_LSEND Codes

DONE	ERROR	STATUS	Meaning
0	1	8301 _H	SAP not activated on destination station.
0	1	8302 _H	No receive resources on the destination station; the receiving station cannot process received data quickly enough or has not prepared any receive resources.
0	1	8303 _H	The SDA service (Send Data with Acknowledge) is not supported on this SAP of the destination station (no SDA with Ethernet).
0	1	8304 _H	The connection is not established. The send job should only be attempted again after waiting for at least 100 ms.
0	1	8311 _H	The destination station cannot be obtained under the specified Ethernet address.
0	1	8312 _H	Ethernet error on the CP.
0	1	8F22 _H	Source area invalid, for example: Area does not exist on the DB LEN parameter < 0
0	1	8F24 _H	Area error reading a parameter.
0	1	8F28 _H	Alignment error reading a parameter.
0	1	8F32 _H	The DB number in the parameter is too high.
0	1	8F33 _H	DB number error.
0	1	8F3A _H	Destination area not loaded (DB).
0	1	8F42 _H	Timeout reading a parameter from the I/O area.
0	1	8F44 _H	Address of the parameter to be read is disabled in the access track.
0	1	8F7F _H	Internal error, e.g. illegal ANY reference. e.g. parameter LEN=0
0	1	8090 _H	No module with this address exists or the CPU is in the STOP mode.
0	1	8091 _H	Module base address not at a double word boundary.
0	1	8092 _H	In the ANY reference, a type other than BYTE is specified. (S7-400 only)
0	1	80A4 _H	The communication bus connection between the CPU and CP is not established. (Only with newer CPU versions)
0	1	80B0 _H	Module does not recognize data record.
0	1	80B1 _H	The specified length (in the LEN parameter) is incorrect.
0	1	80B2 _H	The communication bus connection between the CPU and CP is not established.
0	1	80C0 _H	Data record cannot be read.
0	1	80C1 _H	The specified data record is currently being processed.
0	1	80C2 _H	There are too many jobs pending.
0	1	80C3 _H	CPU resources (memory) occupied.

Table 5-2 AG_SEND / AG_LSEND Codes

DONE	ERROR	STATUS	Meaning
0	1	80C4 _H	Communication error (occurs temporarily and a repetition in the user program will often remedy the problem).
0	1	80D2 _H	Module base address incorrect.

5.3.2 FC6 AG_RECV / FC60 AG_LRECV

Meaning of the Block

The AG_RECV / AG_LRECV function receives the data transferred on a configured connection from the Ethernet CP.

The data area specified for data acceptance can be a process image area, a memory bit area or a data block area.


Error-free execution is indicated when the data were received from the Ethernet CP.

Note:

Unless otherwise stated, all the following information applies to both the FCs AG_RECV and AG_LRECV.

Call

Call interface in LAD representation



Example in STL representation

STL	Explanation
<code>call fc 6</code>	<code>//AG_RECV/AG_LRECV block call</code>
<code>ID := MW 40</code>	<code>//Connection ID acc. to configuration</code>
<code>LADDR := W#16#0100</code>	<code>//=LADDR 256 dec. in hardware config.</code>
<code>RCV := P#M 0.0 BYTE 100</code>	<code>//Buffer for received data</code>
<code>NDR := DB 110.DBX 0.6</code>	<code>//Receive code</code>
<code>ERROR := DB 110.DBX 0.7</code>	<code>//Execution code</code>
<code>STATUS := DB 110.DBW 2</code>	<code>//Error code</code>
<code>LEN := DB 110.DBW 4</code>	<code>//Status code</code>

Notice

Please note the following special feature on TCP connections:

With the S7 CPs for S7-400, you must use FC AG_LRECV on TCP connections!




With the latest S7 CPs for S7-300, you must also use FC AG_RECV for TCP connections.

How the Block Works

The following diagram illustrates the normal sequence of data acceptance triggered by an AG_RECV in the user program.

Each AG_RECV job in the user program is acknowledged by the Ethernet CP with an entry in the output parameters NDR, ERROR and STATUS.



Legend:

1) Parameter transfer NDR, ERROR, STATUS

The status code is updated at each block call.

Explanation of the Formal Parameters

The following table explains all the formal parameters for the AG_RECV / AG_LRECV function.

Parameter	Declaration	Type	Possible Values	Remarks
ID	INPUT	INT	1,2 to 16	The connection number of the ISO transport connection is specified in the ID parameter (See configuration Section 4.3.1)
LADDR	INPUT	WORD		Module start address When you configure the CP with STEP 7 hardware configuration, the module base address is displayed in the configuration table. Specify this address here.
RECV	INPUT	ANY		Specifies address and length The address of the data area refers to one of the following: – Process image area – Bit memory – Data block area Note on length: Performance is improved in transfer of data records up to 212 bytes if you also restrict the length to 212 with the RECV parameter.
NDR	OUTPUT	BOOL	0: – 1: new data	This parameter indicates whether new data were received. For the meaning of this parameter in conjunction with the ERROR and STATUS parameters, refer to the following table.
ERROR	OUTPUT	BOOL	0: – 1: error	Error code For the meaning of this parameter in conjunction with the DONE and STATUS parameters, refer to the following table.
STATUS	OUTPUT	WORD	see following table	Status code For the meaning of this parameter in conjunction with the NDR and ERROR parameters, refer to the following table.

Parameter	Declaration	Type	Possible Values	Remarks
LEN	OUTPUT	INT	<p>On ISO Transport and ISO-on-TCP: 1,2 to 8192</p> <p>On UDP: 1,2 to 2048</p>	<p>Specifies the number of bytes accepted from the Ethernet CP and entered in the data area.</p> <ul style="list-style-type: none"> Note the block type: <ul style="list-style-type: none"> S7-300 With older versions of FC AG_RECV (up to V3.0), the data area is always restricted to a maximum of 240 bytes. The current versions allow up to 8192 bytes. S7-400 With FC AG_RECV, the data area is restricted to a maximum of 240 bytes.

Return Codes

The following table shows the meaning of the information provided by NDR, ERROR and STATUS that must be evaluated by the user program.

Note

For entries coded with 8Fxx_H in STATUS, refer to the information in the STEP 7 Standard and System Functions reference manual. The chapter describing error evaluation with the RET_VAL output parameter contains detailed information.

To find out which SFCs are used and are relevant for error evaluation, display the properties dialog of the FC described here in the “Calls” tab.

Table 5-3 AG_RECV / AG_LRECV Codes

NDR	ERROR	STATUS	Meaning
1	0	0000 _H	New data accepted.
0	0	8180 _H	There are not yet any data available.
0	0	8181 _H	Job active.
0	1	8183 _H	No configuration or the ISO transport service has not yet started on the Ethernet CP.
0	1	8184 _H	System error (the source data area is incorrect).
0	1	8185 _H	Destination buffer (RECV) is too short.
0	1	8186 _H	ID parameter invalid. ID != 1,2....16 (S7-300). ID != 1,2....64.(S7-400)

Table 5-3 AG_RECV / AG_LRECV Codes

NDR	ERROR	STATUS	Meaning
0	1	8304 _H	The connection is not established. The send job should only be attempted again after waiting for at least 100 ms.
0	1	8F23 _H	Source area invalid, for example: Area does not exist in the DB.
0	1	8F25 _H	Area error writing a parameter.
0	1	8F29 _H	Alignment error writing a parameter.
0	1	8F30 _H	Parameter is in the write-protected 1st act. data block.
0	1	8F31 _H	Parameter is in the write-protected 2nd act. data block.
0	1	8F32 _H	The DB number in the parameter is too high.
0	1	8F33 _H	DB number error.
0	1	8F3A _H	Destination area not loaded (DB).
0	1	8F43 _H	Timeout writing a parameter to the I/O area.
0	1	8F45 _H	Address of the parameter to be written is disabled in the access track.
0	1	8F7F _H	Internal error, e.g. illegal ANY reference.
0	1	8090 _H	No module with this address exists or the CPU is in the STOP mode.
0	1	8091 _H	Module base address not at a double word boundary.
0	1	8092 _H	In the ANY reference, a type other than BYTE is specified. (S7-400 only)
0	1	80A0 _H	Negative acknowledgment reading from the module.
0	1	80A4 _H	The communication bus connection between the CPU and CP is not established.
0	1	80B0 _H	Module does not recognize data record.
0	1	80B1 _H	Destination area invalid.
0	1	80B2 _H	The communication bus connection between the CPU and CP is not established.
0	1	80C0 _H	Data record cannot be read.
0	1	80C1 _H	The specified data record is currently being processed.
0	1	80C2 _H	There are too many jobs pending.
0	1	80C3 _H	CPU resources (memory) occupied.
0	1	80C4 _H	Communication error (occurs temporarily and a repetition in the user program will often remedy the problem).
0	1	80D2 _H	Module base address incorrect.

5.4 FCs for Access Coordination with FETCH/WRITE

Overview

The following FCs are available for FETCH/WRITE function to coordinate access:

FC	can be used with:		Meaning
	S7 – 300	S7 – 400	
AG_LOCK (FC7)	x	x	Locks external data access with FETCH/WRITE.
AG_UNLOCK (FC8)	x	x	Releases external data access with FETCH/WRITE.

Caution when Configuring

If you use FCs AG_LOCK and AG_UNLOCK, you must specify the following information for S7-400 stations in the configuration:

- in HW Config


In the “Addresses” tab, the option “Address setting for LOCK/UNLOCK” must be selected.

How the Block Works

With these FCs, you can coordinate access to system memory areas so that no inconsistent data are created and transferred. The control is from the user program in the S7 CPU that can, if necessary disable an external FETCH/WRITE access using an AG_LOCK call. After a certain time or after the local write/read access is completed, an AG_UNLOCK job can be used to enable external access again.

Another advantages is that this access lock only applies to the FETCH/WRITE connection specified in the call. If more than one FETCH/WRITE connections are configured, these can, for example, be used for certain specific system areas and a selective access coordination can be implemented.

The following diagram illustrates the usual chronological sequence of memory access coordination controlled in the user program with AG_LOCK and AG_UNLOCK.



The lock job must first be monitored in the user program using the code in the return parameter `LOCKED`. As long as `LOCKED=0` is indicated, it must be assumed that there is still a `FETCH/WRITE` access active.

If `LOCKED=1` is indicated, this shows that the lock is active; data can now be modified by the user program.

The status code is updated at each block call.

5.4.1 FC7 AG_LOCK


Meaning of the Block

Using the AG_LOCK block the data exchange using FETCH or WRITE on the connection selected with the parameter ID is disabled. The LOCKED output indicates whether or not the lock was successful. If the lock was not successful, the job must be triggered again in a later CPU cycle.

The STATUS output indicates the status of the CP for this connection.

Call

Representation of the AG_LOCK Function



Example in STL representation

STL	Explanation
<code>call fc 7</code>	<code>//Block call</code>
<code>ID := DB 100.DBW 2</code>	<code>//Connection ID acc. to configuration</code>
<code>LADDR := W#16#0100</code>	<code>//=LADDR 256 dec. in hardware configuration</code>
<code>STATUS := DB 100.DBW 4</code>	<code>//Status code</code>
<code>LOCKED := DB 100.DBX 0.6</code>	<code>//Status code of access disable</code>

Explanation of the Formal Parameters

The following table explains all the formal parameters for the AG_LOCK function:

Parameter	Declaration	Type	Possible Values	Remarks
ID	INPUT	INT	1,2 to 16 for S7-300 1,2 to 64 for S7-400	The connection number of the connection is specified in the parameter ID. (See configuration Section 4.3.1)
LADDR	INPUT	WORD		Module start address When you configure the CP with STEP 7 hardware configuration, the module base address is displayed in the configuration table. Specify this address here.
LOCKED	OUTPUT	BOOL	0: not (yet) locked 1: locked	Shows the status of the access lock requested on the specified FETCH/WRITE connection.
STATUS	OUTPUT	WORD	see following table	Status code For meaning, refer to the table below.

Return Codes

The following table shows the STATUS code that must be evaluated by the user program.

Table 5-4 AG_LOCK Condition Codes

STATUS	Meaning
7000	CP is not processing a job
7001	FETCH active
7002	WRITE active
8183	FETCH/WRITE not configured for this connection
8186	ID number not in permitted range (e.g. 1 to 64 with S7-400 Industrial Ethernet CPs)

5.4.2 FC8 AG_UNLOCK

Meaning of the Block


Using the AG_UNLOCK function, the external access to system areas on the S7 CPU with FETCH or WRITE on the connection specified by the ID parameter is released.

The next external FETCH/WRITE job to arrive for the CP can then be processed.

The AG_UNLOCK follows an access lock with AG_LOCK.

Call

Representation of the AG_UNLOCK Function



Example in STL representation

STL	Explanation
<code>call fc 8</code>	<code>//Block call</code>
<code>ID := DB 100.DBW 2</code>	<code>//Connection ID acc. to configuration</code>
<code>LADDR := W#16#0100</code>	<code>//=LADDR 256 dec. in hardware configuration</code>
<code>STATUS := DB 100.DBW 4</code>	<code>//Status code</code>

How the Block Works

To release the connection again, the LOCK request bit must be reset by the FC again. The FC also shows the current status using error messages.

Explanation of the Formal Parameters

The following table explains all the formal parameters for the AG_UNLOCK function:

Parameter	Declaration	Type	Possible Values	Remarks
ID	INPUT	INT	1,2 to 16 for S7-300 1,2 to 64 for S7-400	The connection number of the connection is specified in the parameter ID. (See configuration Section 4.3.1)
LADDR	INPUT	WORD		Module start address When you configure the CP with STEP 7 hardware configuration, the module base address is displayed in the configuration table. Specify this address here.
STATUS	OUTPUT	WORD	see following table	Status code For meaning, refer to the table below.

Return Codes

The following table shows the STATUS code that must be evaluated by the user program.

Table 5-5 AG_UNLOCK Condition Codes

STATUS	Meaning
7000	CP is not processing a job
7001	FETCH active
7002	WRITE active
8183	FETCH/WRITE not configured for this connection
8186	ID number not in permitted range (e.g. 1 to 64 with S7-400 Industrial Ethernet CPs)

5.5 Numeric Data / Resource Requirements of the FCs

Notice

Please note the version information of the blocks. Blocks with other versions have different resource requirements.

Table 5-6 Information for FCs with an S7-400

NAME	Version	FC no.	Load Memory Bytes	Work Memory Bytes	MC7 Bytes	Local data Bytes
AG_SEND	1.1	5	732	576	540	20
AG_RECV	1.1	6	656	522	486	20
AG_LOCK	1.1	7	748	636	600	34
AG_UNLOCK	1.0	8	712	604	568	32
AG_LSEND	3.0	50	1044	846	810	52
AG_LRECV	3.0	60	1190	992	956	58

Table 5-7 Information for FCs with an S7-300

NAME	Version	FC no.	Load Memory Bytes	Work Memory Bytes	MC7 Bytes	Local data Bytes
AG_SEND	4.1	5	1916	1596	1574	50
AG_RECV	4.5	6	1408	1156	1138	40
AG_LOCK	4.0	7	748	636	600	34
AG_UNLOCK	4.0	8	712	604	568	32



The NCM S7 Diagnostics described here provides dynamic information on the operating state of the communication functions of online CPs.

This chapter provides a general overview of the individual diagnostic functions.

The following checklist will help you to recognize several typical problems and their possible causes and shows how you can use the NCM S7 for PROFIBUS diagnostics tool to remedy the situation.



Further information is available from the following sources:

- When you are working with the diagnostic tool, the integrated help system provides you with context-related support.
- You will find detailed information on working with STEP 7 programs in the Help on STEP 7, which includes the topic “Diagnosing Hardware”.

6.1 Overview

Diagnostic Options in STEP 7

STEP 7 provides you with a graded concept allowing you to query information about the status of your SIMATIC S7 components and functions and to sort out problems in a variety of different situations. These options cover the following:

- **Hardware Diagnostics and Troubleshooting with STEP 7**

Hardware diagnostics provides dynamic information on the operating mode of modules including CPs when the S7 station is online.

You can recognize the existence of diagnostic information for a module by the diagnostics icon in the project window of the SIMATIC Manager. Diagnostic icons show the status of the corresponding module and also the operating mode of CPUs.

Detailed diagnostic information is displayed in the “module information” that you can open by double-clicking a diagnostic icon in the quick view or the diagnostic view.

- **Communication Diagnostics with NCM S7 Diagnostics**

The NCM S7 Diagnostics described here provides dynamic information on the operating state of the communication functions of online CPs.

- **HW Config Provides Static Information**

Static information means the configured communication properties of an online or offline CP and you can display this at any time using the hardware configuration shown by HW Config.

What You Should Already Know

You should be familiar with the basic information from Chapter 2 about handling NCM S7. This means that you know how to connect the Ethernet CP to the PG and how to control the module using the PG.

Where to Find Further Information



Further information is available from the following sources:

- Information about the communication services is available in the appropriate chapters in this manual.
- When you are working with the diagnostic tool, the integrated help system provides you with context-related support.
- You will find detailed information on working with STEP 7 programs in the Help on STEP 7, which includes the topic “Diagnosing Hardware”.

6.2 Functions of NCM S7 Diagnostics

Functions

The diagnostic functions can be grouped as follows:

- General diagnostic and statistical functions
- Type and mode-dependent diagnostic functions

General Diagnostic and Statistical Functions

Regardless of the configured mode of the Ethernet CP, the following diagnostic functions are possible:

- Querying the operating mode on Ethernet
- Querying the event messages recorded on the Ethernet CP (diagnostic buffer)

Mode-Dependent Functions

Depending on the configured mode of the Ethernet CP, the following diagnostic functions are possible:

- Diagnostics of ISO transport connections
- Diagnostics of ISO-on-TCP connections
- Diagnostics of TCP connections
- Diagnostics of UDP connections
- Diagnostics of E-mail connections

6.2.1 Installing and Starting NCM S7 Diagnostics

Installation

NCM S7 Diagnostics is an integrated component of the NCM S7 for Industrial Ethernet optional package.



NCM S7 Ethernet Diagnostics is installed along with NCM S7 for Ethernet on your PG.

There are several ways in which you can start the diagnostic tool:

Alternative 1




- From the standard Start menu of Windows (program group SIMATIC►...►NCM).

Use this method if the STEP 7 project in which the CP was configured is not available on your PG (for service purposes).




Alternative 2

- From the Properties dialog of the CP within your STEP 7 project.



Structure

In the same way, for example, as the SIMATIC Manager, NCM S7 Diagnostics appears as a separate two-part application window with a menu and toolbar:



- In the **navigation area** on the left-hand side, you will find the hierarchically arranged diagnostic objects.
You have an overview of the available diagnostic functions at all times. The object structure displayed in the navigation area is adapted to the type of CP you are currently checking and the functions and connections configured for the CP.
- In the **content area**, on the right-hand side, you will see the result of the diagnostic function you selected in the navigation area.

Working in the Dialog

- By selecting a diagnostic object in the navigation area with the mouse, you execute the diagnostic function.
- Using the **menu bar and toolbar**, you control the sequence of the diagnostics with context-sensitive menu commands.

6.2.2 General Menu Commands

Overview

When running diagnostic functions, the following menu commands have general significance. Depending on the context, other functions may be available; for more detailed information refer to the online help for NCM Diagnostics.

Table 6-1 Meaning of the Menu Commands

Menu	Meaning
Diagnostics ► Open Online Connection... Diagnostics ► Close Online Connection...	With this menu command, you can establish a connection to a different CP you want to check without having to quit and restart the diagnostic tool. The current diagnostic connection is closed. If you want to use more than one diagnostic connection at the same time, you can start NCM S7 diagnostics more than once.
Operating Mode ► Stop CP Start CP Reset CP	You can control the CP as follows: Stops the CP. Starts the CP if the RUN/STOP switch is set to RUN. With certain CP types, for example the CP 443-5 Basic, you can reset the CP memory. This function must be confirmed before it is executed.
View►Update	Each time you activate this menu command, the displayed diagnostic and status information is updated once.
View ► Update Cyclically	Using this menu command, you activate and deactivate the automatic (cyclic off) updating of the displayed diagnostic and status information. You can set the interval between update points with the menu command Options ► Customize .
Options ► Customize	With this menu command, you set the general parameters for the diagnostic session. On Ethernet: <ul style="list-style-type: none"> • Dialog update time This sets the interval at which the diagnostic data are updated in a contents area when cyclic updating is selected. • Show TSAP in ASCII You can decide whether the TSAP is shown in ASCII or hexadecimal in the following tab page dialogs.
Help ►	You can obtain help about the current diagnostic function As an alternative, you can also press the F1 key. Remember that you can also call up context-related help for some of the diagnostic functions. To obtain help, position the cursor on the output field and press the F1 key.

Note

If the connection to the CP is terminated during the diagnostic session, the following message is displayed: "The online connection was terminated".

You can reestablish the connection to the CP with the corresponding acknowledgment in the dialog. The connection is then automatically reestablished whenever possible.

6.3 Starting Diagnostics – Establishing a Connection to the Ethernet CP

Initial Situation

Establish the physical connection between the PG and the SIMATIC S7 Station. There are two ways of doing this:

- MPI
- Industrial Ethernet
- Industrial Ethernet TCP/IP
- PROFIBUS

Starting Diagnostics from the NCM Program Group

If there are no configuration data on your PG/PC, follow the steps outlined below to start diagnostics with a connected CP:

1. Select the function “NCM Diagnostics” in the NCM S7 program group.
NCM S7 Diagnostics is started with the message “No online connection to the CP” in the contents area.
2. Select the **“Diagnostics►Open Online Connection...”** menu command.
3. In the displayed dialog “NCM S7 Diagnostics”, select the interface to match your hardware configuration.

Depending on the type of network attachment you have, you will be prompted to specify an address:

Table 6-2 Possible Settings for the Online Paths – without Parameters for Internetworking

Attachment on Destination Station	Node Address	Location of the Module Rack / Slot
MPI	MPI address of the CP if this has its own MPI address. Otherwise specify the MPI address of the CPU.	Rack/slot no. of the CP to be checked. If you specify the MPI address of the CP, you can simply use the default setting “0/0”. With this setting, the CP whose address was specified as the node address is accessed.
PROFIBUS	PROFIBUS address of the PROFIBUS CP via which the S7 station is reached.	Rack/slot no. of the CP to be checked.

Table 6-2 Possible Settings for the Online Paths – without Parameters for Internetworking

Attachment on Destination Station	Node Address	Location of the Module Rack / Slot
Industrial Ethernet	MAC address of the Ethernet CP via which the S7 station is reached. Entered in hexadecimal.	Rack/slot no. of the CP to be checked. If you specify "0/0", the CP specified with the node address is accessed directly.
Industrial Ethernet TCP/IP	IP address of the Industrial Ethernet CP via which the S7 station is reached. Entered in decimal. Example: IP address decimal 142.120.9.134	Rack/slot no. of the CP to be checked. If you specify "0/0", the CP specified with the node address is accessed directly.

Internetworking

If the CP you want to check with diagnostic functions can only be reached via a gateway, you must select the device and specify its node address in the local network.

You must also specify the S7 subnet ID of the destination network:

The subnet ID consists of two numbers separated by a dash:

- One number for the project
- One number for the subnet

You will find the subnet ID in the object properties of the subnet in the STEP 7 project. The subnet ID is also printed out with the network configuration.

Starting Diagnostics from the Properties Dialog of the CP

If the project data are available on your PG/PC, follow the steps outlined below:

1. Select the S7 station in the project and open the hardware configuration (HW Config).
2. Select the CP and open the Properties dialog.
3. Select the "Diagnostics" dialog.
4. Select the "Run" button.

Result:

NCM S7 Diagnostics is opened. The path is set automatically to match the current connection in STEP 7.

Other Startup Options

In the Properties dialog of the connections:

1. Select the **PLC►Activate Connection Status** menu command to activate online access.
2. Select the “Special Diagnostics” button in the “Status Information” tab.

In the hardware configuration tool HW Config:

1. With the S7 station online, select the **PLC►Module Status** menu command;
2. Select the “Special Diagnostics” button in the dialog that is opened.

Note

To operate several diagnostic connections at the same time, you can start NCM S7 Diagnostics more than once.

You can also start NCM S7 Diagnostics twice with an online connection to the same CP; this can, for example, be useful if you want to monitor the diagnostic buffer at the same time as running diagnostic functions on a connection.


Requirement: You have an online connection available via the LAN (ISO or TCP/IP) on the one hand and an online connection via the communication (K) bus on the other (alternatively via the CPU or via PG channel routing via a further CP).

6.4 How to Use Diagnostics

Procedure

To use diagnostics efficiently, particularly when working with the diagnostic tool for the first time, the following procedure can be recommended.

1. Use the sequence shown below as a basis for using diagnostics:



2. Pinpoint your problem or task, for example based on the checklist in Section 6.6 and select the diagnostic function you require based on the recommendation in the list.

6.5 Call-Specific Diagnostic Functions

The following table shows the diagnostic options that exist in the available functions.

Table 6-3 General Diagnostic and Statistical Functions

Diagnostic Functions / Diagnostic Object	Diagnostic Aims	Special Features
CP information	The aim is to identify the CP to which NCM S7 Diagnostics is connected and to find out the current mode.	
Mode	Here, the aim is to find out the current operating mode of the Ethernet CP as a module in the S7-300/400 and as a node on Ethernet and, if necessary, to modify the mode (menu command Operating Mode►Stop CP/Start CP).	
Diagnostic buffer	<p>General Error Diagnostics Using Diagnostic Buffers:</p> <p>To display and decode event messages recorded on the CP in detail. The diagnostic buffer provides you with detailed information about all the communication services of the CP.</p>	<p>Event messages are recorded on the CP in a ring buffer. The ring buffer can contain up to 50 entries.</p> <p>In NCM S7, on the other hand, up to 500 messages can be saved!</p> <p>All the CP functions can generate event messages. When you call the diagnostic object, the messages are read out and displayed. The latest message is displayed in the top line with the highest consecutive number.</p> <p>If you double-click a previously selected event message, you display a help text explaining the message in greater detail.</p>

Table 6-4 Mode-Dependent Functions

Diagnostic Functions / Diagnostic Object	Diagnostic Aims	Special Features
To display and monitor communication connections. You obtain an overview or detailed information in the contents area depending on the diagnostic object you select.		
Connections	<ul style="list-style-type: none"> • Overview of All Connection Types Used 	By double-clicking the objects in the contents area, you can display detailed information.
Connections ▶ Type	<ul style="list-style-type: none"> • Overview of all the communication connections of a particular type, for example all TCP connections; • Information on the connection status 	
Connections ▶ Type ▶ Type-connection-n	<ul style="list-style-type: none"> • Detailed information about the status of a communication connection. 	

6.6 Checklist for ‘Typical Problems‘ in a System

Meaning

The following lists contain several typical problems and their possible causes and how you can use the NCM S7 Ethernet Diagnostics tool to remedy the situation.

The checklists deal with the following topics:

1. Checklist for General CP Functions
2. Communication Connections Checklist

Note

In the column “Identifying the Cause and Remedy”, you will see the diagnostic function recommended for dealing with the problem shown in bold face.

6.6.1 Checklist for General CP Functions

Table 6-5 Checklist for Typical Problems When Operating a CP in a System

Problem	Possible Cause	Identifying the Cause and Remedy
The Ethernet CP will not change to the RUN mode.	Invalid configuration loaded on the Ethernet CP.	<p>Yellow STOP LED and red SF LED lit continuously.</p> <p>Call up the diagnostic buffer in NCM S7 Ethernet Diagnostics.</p> <p>Example of an entry</p> <p>The maximum number of entries for ISO transport connections was exceeded</p> <p>Further entry:</p> <p>CP STOP due to invalid CP parameter assignment</p> <p>What to do:</p> <p>Correct the configuration of the Ethernet CP.</p>
	Switch set to STOP on the Ethernet CP.	<p>Query the operating mode in NCM S7 Diagnostics.</p> <p>Operating mode: STOP, Cause: switch set to STOP</p> <p>What to do:</p> <p>Change the switch to RUN on the Ethernet CP</p>

6.6.2 Communication Connections Checklist

Table 6-6 Checklist for Typical Problems with ISO Transport / ISO-on-TCP / UDP Connections

Problem	Possible Cause	Identifying the Cause and Remedy
No data transfer on an ISO transport connection / ISO-on-TCP connection or only in one direction.	AG-SEND and AG-RECV are not called in the user program. or Receive or send buffer too small or incorrect.	Check the user program. Evaluate status bytes in AG-SEND and AG-RECV. What to do: If necessary, configure FC blocks. If necessary, correct ANY pointer.
	The connection is not established.	Evaluate status bytes of the FC blocks or evaluate diagnostic buffer. What to do: Change the address parameters (MAC/IP address, TSAP).
Data transfer too slow	Receiving device too slow	Evaluate diagnostic buffer. Entry: "No receive resources on destination station XX". What to do: Delay the send trigger or check the destination station and optimize reception.
The complete data field is not sent on an ISO transport / ISO-on-TCP/UDP connection.	LEN parameter for AG-SEND is set to the wrong value.	What to do: Set the LEN parameter to the required size.
The complete data field is not sent on an ISO transport / ISO-on-TCP/UDP connection.	The buffer specified with the ANY pointer is too small.	What to do: Correct the LEN parameter and the ANY pointer.



Firmware Loader

7

This chapter will familiarize with the uses and handling of the Firmware Loader.

The firmware loader allows you to download more recent firmware versions to the SIMATIC NET CPs.

7.1 Application

Firmware

Here, firmware means the system programs in the SIMATIC NET CPs.

Uses of the Firmware Loader

The firmware loader allows you to download more recent firmware versions to the SIMATIC NET CPs. It is used on the following:

- PROFIBUS CPs
- Industrial Ethernet CPs

Installation

The firmware loader is available when you have installed NCM on your PG/PC.

Load Files

The firmware loader supports the following file types:

- <file>.LAD

A file form containing only the system program that can be downloaded to the CP.

- <file>.FWL

A file form that contains information that can be displayed in the dialogs of the firmware loader in addition to the LAD file form.



For detailed information, read the documentation, for example, the README file shipped with the load file.

Working with the Firmware Loader


Depending on the CP type, the downloading is prepared and executed in three or four steps.

For more detailed information, refer to the next section and the dialog boxes themselves.

7.2 Loading Firmware

Starting the Download

Start the program from the Windows standard Start menu using the **SIMATIC ▶NCM S7 ▶ Firmware Loader** menu command.



Select the **Next** button and follow the instructions displayed in the dialog.

1st Step

Select the firmware to be downloaded using the **Browse...** button.

The text box for selecting files also displays a list box in which the last ten selected load files are displayed and can be selected.

With FWL load files, the comment box may also contain additional information about the file.



Caution

Make sure that the load file you are using is intended as an update for the version of the firmware contained on your CP. If you are in any doubt, contact your local Siemens advisor.

2nd Step

Select the interface via which you want to download the firmware.

The interface type (PROFIBUS or Industrial Ethernet) is already decided by the load file you selected.

- For a PROFIBUS CP:
There are no further settings in this dialog; go to the next step.
- For an Industrial Ethernet CP:
Select or specify the MAC address of the Ethernet CP and go to the next step.

Note

The following applies to an Industrial Ethernet CP:

If a download was previously aborted to the particular CP you must click the **Emergency Address** button. In this case, it is assumed that there was a memory reset on the CP which is now only accessible using an emergency address.

With **newer CPs (order number 6GK7 x43-1EX11-0XE0 and later)**, a fixed MAC address assigned to the CP is used instead of an emergency address. Please refer to the information in the relevant manual /1/ on the topic of "Downloading New Firmware".

3rd Step

Check the configuration.

You can check and adjust settings for the PG/PC interface using the **Modify...** button.

Set the PG/PC interface according to the CPs available on your PG (list box "Device Parameter Sets") and according to the bus attachment (list box "Properties").

For more detailed information, refer to the integrated help system.

Continue to follow the instructions in the dialog to establish the connection to the Ethernet CP.



Caution

Remember that interrupting the download can lead to an inconsistent state on the CP.

With Industrial Ethernet, please note the instruction in the second step for displaying the emergency address.

Using the **Modify...** button, you can set the PG/PC interface back to its original values.

For more detailed information, refer to the integrated help system.



References

/1/

Product informationen bulletin / manual SIMATIC NET CP
Supplied with the specific CP
Siemens AG

/2/

NCM S7 for PROFIBUS Primer
Part of the documentation package NCM S7 for PROFIBUS
Part of the online documentation in the STEP 7 optional package NCM
SIEMENS AG

/3/

NCM S7 for Industrial Ethernet Primer
Part of the documentation package NCM S7 for Industrial Ethernet
Part of the online documentation in the STEP 7 optional package NCM
SIEMENS AG

/4/

SIMATIC NET IT-CP, Manual
Part of the documentation package NCM S7 for Industrial Ethernet
SIEMENS AG

/5/

SIMATIC STEP 7 Configuring Hardware with STEP 7
Part of the standard STEP 7 Documentation Package
Part of the online documentation in STEP 7
SIEMENS AG

/6/

SIMATIC Communication with SIMATIC
Manual
SIEMENS AG

/7/

SIMATIC STEP 7 Programming with STEP 7
Part of the standard STEP 7 Documentation Package
Part of the online documentation in STEP 7
SIEMENS AG

/8/

SIMATIC STEP 7 Reference Manual Documentation Package
SIEMENS AG

/9/

SIMATIC NET Industrial Twisted Pair Networks
SIEMENS AG

/10/

Ethernet, IEEE 802.3
(ISO 8802-3)

/11/

SINEC CP 1413
Manuals for MS-DOS, Windows
SIEMENS AG

/12/

SIMATIC S7
S7-300 Programmable Controller
Hardware and Installation
Manual
SIEMENS AG

/13/

SIMATIC NET Manual for Triaxial Networks
SIEMENS AG

/14/

SIMATIC NET Ethernet Manual
SIEMENS AG

/15/

Lokale Netze –
Kommunikationsplattform der 90er Jahre
Andreas Zenk
Addison–Wesley
ISBN 3-89319-567-X

/16/

TCP/IP
Internet-Protokolle im professionellen Einsatz
Mathias Hein
International Thomson Publishing
ISBN 3-8266-400-4
ITP Online-Center: <http://www.ora.de>

/17/

RFC1006 (Request For Comment)

/18/

RFC793 (TCP)

/19/

RFC791 (IP)

/20/

Berger, Hans
Automation with STEP 7
SIMATIC S7-300/400 Programmable Logic Controllers

Order Numbers

The order numbers for the SIEMENS documentation listed above can be found in the catalogs “SIMATIC NET Industrial Communication, Catalog IK PI” and “SIMATIC Programmable Controllers SIMATIC S7 / M7 / C7”.

You can obtain these catalogs and any further information you require from your local SIEMENS office or national head office.



Glossary

B

B.1	General Section	184
B.2	Ethernet	188

B.1 General Section

Baud rate

→ transmission rate

Bus Segment

Part of a → subnet. Subnets can consist of bus segments and connectivity devices such as repeaters and bridges. Segments are transparent for addressing.

Client

A client is a device or, in general terms, an object that requests a service from a → server.

Configuration Data

Parameters that determine the modes and functions of a → CP. They are set and downloaded using the NCM S7 configuration tool.

CP

Communications processor. Module for communications tasks.

CSMA/CD

CSMA/CD (Carrier Sense Multiple Access with Collision Detection)

FC

STEP 7 logic block of the type "function".

Frame

A message from one PROFIBUS/Ethernet station/node to another.

Frame Header

A frame header consists of an identifier for the → frame and the source and destination address.

Frame Trailer

A frame trailer consists of a checksum and the end identifier of the → frame.

Gateway

Intelligent connectivity device that connects local area→ networks of different types at the ISO Layer 7 level.

Industrial Ethernet

A fieldbus complying with IEEE 802.3 (ISO 8802–2)

NCM S7 for Industrial Ethernet

Configuration software for configuration and diagnostic functions on an Ethernet CP.

NCM S7 for PROFIBUS

Configuration software for configuration and diagnostic functions on a PROFIBUS CP.

Network

A network consists of one or more interconnected → subnets with any number of → stations. Several networks can exist side by side.

PG Mode

A mode of the PROFIBUS/Ethernet CP in which the SIMATIC S7-CPU is programmed, configured or checked via PROFIBUS/Ethernet. This mode is handled by the S7 functions.

Process Image

The process image is a special memory area in the programmable logic controller. At the start of the cyclic program, the signal states of the input modules are transferred to the process input image. At the end of the cyclic program, the process output image is transferred as a signal state to the output modules.

Protocol

A set of rules for transferring data. Using these rules, both the formats of the frames and the data flow are specified.

Segment

Synonym for → bus segment.

Server

A server is a device, or in general terms, an object that provides certain services. A service is started at the instigation of a → client.

Services

Services provided by a communication protocol.

SIMATIC NET

Siemens SIMATIC Network and Communication. Product name for → networks and network components from Siemens (previously SINEC).

SIMATIC NET for Ind. Ethernet

SIMATIC NET bus system for industrial applications based on Ethernet (previously SINEC H1)

SINEC

Previous product name for → networks and network components from Siemens.
Now: SIMATIC NET

Station

A station is identified by a

- MAC address in the Ethernet network.
- PROFIBUS address in the PROFIBUS network.

Subnet

A subnet is part of a → network whose parameters (for example → PROFIBUS) must be matched. It includes the bus components and all attached stations. Subnets can, for example, be connected together by → gateways to form a network.

A → system consists of several subnets with unique → subnet numbers. A subnet consists of several → stations with unique → PROFIBUS or MAC addresses (Industrial Ethernet).

System

This means all the electrical equipment within a system. A system includes, among other things, programmable logic controllers, devices for operation and monitoring, bus systems, field devices, actuators, supply lines.

Transmission Rate

According to DIN 44302, this is the number of binary decisions transmitted per time unit. The set or selected transmission rate depends on various conditions, for example the distance across the network. In Ethernet, there is a fixed transmission rate of 10 Mbps.

Transport Interface

The transport interface of a SIMATIC S5 PLC is the access to the connection-oriented services of the transport layer on the CP. The transport interface presents itself to the control program in the form of handling blocks (HDBs).

Transport Layer

The transport layer is layer 4 of the ISO/OSI reference model for open system interconnection. The purpose of the transport layer is to transfer data reliably from device to device. Transport connections can be used for the transmission.

TSAP

Transport Service Access Point

Watchdog

Mechanism for monitoring operability.

B.2 Ethernet

Base Address

Logical address of a module in S7 systems.

- For PROFIBUS

The PROFIBUS base address is the address starting at which all addresses that are calculated automatically in the project are assigned.

- For Industrial Ethernet

The base MAC address is the address starting at which all addresses that are calculated automatically in the project are assigned.

ISO-on-TCP

Transport layer connection (layer 4 communication complying with ISO) simulated on TCP.

On an ISO-on-TCP connection, messages can be exchanged in both directions. TCP provides the data flow communication without segmenting the data into messages. ISO, on the other hand, is message-oriented. With ISO-on-TCP, this mechanism is simulated on TCP. This is described in RFC1006 (Request For Comment).

ISO-on-TCP connections allow program/event-controlled communication via Ethernet from a SIMATIC S7 PLC to

- SIMATIC S7 PLC with Ethernet CP
- SIMATIC S5 PLC with Ethernet CP
- PC/PG with Ethernet CP
- any system

ISO Transport Connection

Communication connection of the transport layer (with the CP/COM 143 previously S5S5 connection).

ISO transport connections allow program/event-controlled communication on Industrial Ethernet between SIMATIC S7 PLCs and

- SIMATIC S7 with an Ethernet CP
- SIMATIC S5 with an Ethernet CP (e.g. CP 143 or CP 1430)
- PC/PG with an Ethernet CP (e.g. CP 1413)
- Any system via the ISO transport protocol (ISO 8073)

The transfer of blocks of data on an ISO transport connection is bi-directional.

MAC Address

Address to distinguish between different nodes connected to a common transmission medium (Ethernet).

Media Access Control (MAC)

Mechanisms for controlling access by a station to a common transmission medium shared with other stations.

RFC 1006

see ISO on TCP

Station (Ind. Ethernet)

A station is identified by a → MAC address in the → Ethernet (SINEC H1) network.

Subnet Mask

The subnet mask specifies which parts of an IP address are assigned to the network number (see ISO-on-TCP). The bits in the IP address whose corresponding bits in the subnet mask have the value 1 are assigned to the network number.

Subnet Number

A → system consists of several → subnets with unique subnet numbers.

TCP/IP

TCP = Transport Connection Protocol; IP = Internet Protocol

UDP

User Datagram Protocol: datagram service for simple internetwork transmission without acknowledgment.



Linking to Other Systems with FETCH/WRITE

C

The FETCH and WRITE modes supported on ISO transport connections and ISO-on-TCP connections can be used with any other system to access the S7 system memory areas.

To be able to use this type of access, for example for PC applications, you need to know the PDU structure of the jobs. The required S7 or S5 header for request and response frames are 16 bytes long and their structure is described in this chapter.

a) Structure of WRITE Frames

The meaning and values of parameters shown without values in the following table can be found in the section "Parameter Values".

WRITE request frame

0	System ID	= "S"
1		= "5"
2	Length of header	= 16d.
3	ID OP code	= 01
4	Length OP code	= 03
5	OP code	= 03
6	ORG field	= 03
7	Length ORG field	= 08
8	ORG ID	
9	DBNR	
A	Start address	High Byte
B		Low Byte
C	Length	High Byte
D		Low Byte
E	Empty field	= FFh.
F	Length empty field	= 02
Data up to 64 K		

WRITE acknowledgment frame

0	System ID	= "S"
1		= "5"
2	Length of header	= 16d.
3	ID OP code	= 01
4	Length OP code	= 03
5	OP code	= 04
6	Ack field	= 0Fh
7	Length S field	= 03
8	Error no	= No
9	Empty field	= FFh
A	Length empty field	= 07
B	free	
C		
D		
E		
F		

b) Structure of FETCH Frames

The meaning and values of parameters shown without values in the following table can be found in the section "Parameter Values".

FETCH request frame

0	System ID	= "S"
1		= "5"
2	Length of header	= 16d.
3	ID OP code	= 01
4	Length OP code	= 03
5	OP code	= 05
6	ORG field	= 03
7	Length ORG field	= 08
8	ORG ID	
9	DBNR	
A	Start address	High Byte
B		Low Byte
C	Length	High Byte
D		Low Byte
E	Empty field	= FFh.
F	Length empty field	= 02

FETCH response frame

0	System ID	= "S"
1		= "5"
2	Length of header	= 16d.
3	ID OP code	= 01
4	Length OP code	= 03
5	OP code	= 06
6	Ack field	= 0Fh
7	Length ack field	= 03
8	Error no	= Nr
9	Empty field	= FFh
A	Length empty field	= 07
B	free	
C		
D		
E		
F		
Data up to 64 K but only if Error no. = 0		

Parameter Values

S7 Address Area	DB	M	I	Q
ORG ID	01 _H Source/dest. data from/to data block in main memory	02 _H Source/dest. data from/to flag area	03 _H Source/dest. data from/to process image of the inputs (PII)	04 _H Source/dest. data from/to process image of the outputs (PIQ)
DBNR	DB, from which the source data are taken or to which the dest data are transferred	irrelevant	irrelevant	irrelevant
permitted range	1...255			
Start address	DW number, from which the data are taken or written to	Flag byte no., from which the data are taken or written to	Input byte no., from which the data are taken or written to	Output byte no., from which the data are taken or written to
permitted range	0...2047	0...255	0...127	0...127
Length	Length of the source/dest. data field in words	Length of the source/dest. data field in bytes	Length of the source/dest. data field in bytes	Length of the source/dest. data field in bytes
permitted range	1...2048	1...256	1...128	1...128


S7 Address Area	P/PQ	C	T
ORG ID	05 _H Source/dest. data from/to in I/O modules. With source data input modules, with dest data output modules	06 _H Source/dest data from/to counter cells	07 _H Source/dest data from/to timer cells
DBNR	irrelevant	irrelevant	irrelevant
Start address	I/O byte no., from which the data are taken or written to	Number of the counter cell from which the data are taken or written to	Number of the timer cell from which the data are taken or written to
permitted range	0...127 digital I/Os 128...255 analog I/Os	0...255	0...255
Length	Length of the source/dest. data field in bytes	Length of the source/dest. data field in words (counter cell = 1 word)	Length of the source/dest. data field in words (counter cell = 1 word)
permitted range	1...256	1	1



SIMATIC NET – Support and Training

Customer Support, Technical Support

Open round the clock, worldwide:



SIMATIC Hotline

Technical Support	Authorization Hotline
Europe and Africa (Nuremberg) Mo. to Fr. 7:00 to 17:00 (local time, GMT +1) Tel: +49 – (0) 180 – 5050 – 222 Fax: +49 – (0) 180 – 5050 – 223 E-mail: techsupport@ad.siemens.de	Europe and Africa (Nuremberg) Mo. to Fr. 7:00 to 17:00 (local time, GMT +1) Tel: +49 – (0) 911 – 895 – 7200 Fax: +49 – (0) 911 – 895 – 7201 E-mail: authorization@nbgm.siemens.de
America (Johnson City) Mo. to Fr. 8:00 to 19:00 (local time, GMT –5) Tel: +1 – (0) 423 – 262 – 2522 Fax: +1 – (0) 423 – 262 – 2231 E-mail: simatic.hotline@sea.siemens.com	
Asia and Australia (Singapore) Mo. to Fr. 8:30 to 17:30 (local time, GMT +8) Tel: +65 – (0) 740 – 7000 Fax: +65 – (0) 740 – 7001 E-mail: simatic.hotline@sae.siemens.com.sg	
SIMATIC Premium Hotline	
Worldwide (Nuremberg) Workdays 0:00 to 24:00 (local time, GMT +1) Tel: +49 – (0) 911 – 895 – 7777 Fax: +49 – (0) 911 – 895 – 7001 E-mail: techsupport@ad.siemens.de	Fast callback guaranteed within a maximum of two hours (charged, only with the SIMATIC Card)

Technical Support Online Services

SIMATIC Customer Support provides you with a wide range of additional information on SIMATIC products in the online services:

- You can obtain general up-to-date information as follows:
 - on the Internet at
<http://www.siemens.de/simatic-net>
 - at fax polling no. +49 (0) 8765-93 02 77 95 00
- Updated product information, FAQs, Tips and Tricks, and useful downloads are available from the following sources:
 - on the Internet at
<http://www.siemens.de/automation/service&support>
 - From the bulletin board system (BBS) in Nuremberg (*SIMATIC Customer Support Mailbox*) at the number +49 (0) 911 895-7100.

To dial the mailbox, use a modem with up to V.34 (28.8 Kbaud), with the following parameters: 8, N, 1, ANSI, or dial on ISDN (x.75, 64 Kbits).

Training Center

Courses are available to help you become familiar with the SIMATIC S7 automation system and programmable controllers. Please contact your regional training center or the central training center in D 90327 Nuremberg.

Tel. +49 (0) 911–895–3154

Infoline: Tel. +49 (0) 1805 23 56 11
Fax. +49 (0) 1805 23 56 12

Internet: <http://www.sitrain.com>

E-mail: AD–Training@nbgm.siemens.de

The H/F Competence Center in Nuremberg offers a special workshop on the topic of fault-tolerant SIMATIC S7 programmable controllers. The H/F Competence Center also supports you during configuration, when putting your system into operation and if you have problems on site.

Tel. +49 – (0) 911 – 895 – 4759

Fax. +49 – (0) 911 – 895 – 5193

E-mail: hf–cc@nbgm.siemens.de
CoC–SI@nbgm.siemens.de

Further Support

If you have further questions about SIMATIC NET products, contact your local Siemens representative.

You will find the addresses:

- In our catalog IK PI
- on the Internet at
<http://www.siemens.de/automation/partner>
- in the interactive catalog CA01
<http://www.siemens.de/automation/ca01>
- on the Quick Start CD



A

- Access coordination, 146
- Address parameters
 - broadcast, 118
 - unspecified ISO-on-TCP connection, 98
 - unspecified TCP connection, 107
 - unspecified UDP connection, 117
- AS-Interface, 14

B

- Broadcast, with UDP, 115

C

- Communication options, 15
- Communication services, configuring, 53
- Configuration data, downloading to the PLC, 54
- Connection, properties, 70
- Connection configuration, 69
- CP address, 124
- CP configuration data, saving, 55
- Creating a subnet, 40
- CSMA/CD, 14

D

- Diagnostics, 49
- Displaying network attachments, 44
- Dynamic properties, 87

E

- Ethernet, overview, 14
- Ethernet CP
 - further CP properties, 46
 - time, 47
 - installing and starting, 37
 - procedure, 39

F

- FCs
 - block number, 124
 - general notes, 124
- FCs for access coordination with FETCH/WRITE, 146

FETCH/WRITE services

- configuration for ISO-on-TCP, 99
- configuration for ISO transport, 89
- configuration for TCP, 108
- overview, 27

Firmware Loader, 169

- application, 170
- loading firmware, 171

Functions

- AG-RECV, 58, 59
- AG-SEND, 58, 59

Functions (FCs)

- AG_LOCK, 148
- AG_LOCK / AG_UNLOCK, 146
- AG_RECV / AG_LRECV, 140
- AG_SEND / AG_LSEND, 134
- AG_UNLOCK, 150
- for configured connections, 130
- typical sequence, 60

Further functions, 77

H

- Hardware configuration, Ethernet CP, 42

I

- Industrial Ethernet, overview, 14
- ISO transport connection, 81
 - amount of data and number of connections, 70
 - checking, 91
 - connection without assignment, 78
 - dynamic properties, 87
 - printing configured connections, 77
 - properties dialog, 81
 - addresses, 85
 - dynamics, 87
 - general, 82
 - overview, 91
 - save connection, 77
 - unspecified connection, 86
- ISO-on-TCP connection
 - addresses, 96
 - checking, 101
 - properties, 93
 - specifying the partner, 94

J

Job header, 132

N

NCM S7
 general information, 38
 installation, 38
NCM S7 Diagnostics, 153
 overview, 154
Network access, 14
New connection, 73, 74

O

Operator interface devices, 21, 22
Other station, 28, 75
 configuring, 50
 connecting a subnet, 51

P

PG operation
 with STEP 7 on Ethernet, 20
 with STEP 7 via Ethernet, 18
PG/PC interface, 22
PROFIBUS, 14
Project variant
 1 subnet – 1 project, 30
 1 subnet – more than 1 project, 33
 2 or more subnets – 1 project, 32
 more than 1 subnet – more than 1 project,
 34
 several subnets several projects, 35
 SIMATIC S5 and non-SIMATIC devices, 31

R

Routing, 122

S

S7 communication on Ethernet, 15, 22
S7 communication relay, 15, 22
S7 functions, 15
SEND/RECEIVE interface, 15
 CPU cycle, 62
 data exchange, 58
 overview, 24
 user program, 59
SIMATIC NET, 14
System memory, access using
 FETCH/WRITE, 90, 100, 109

T

TCP connection, 102
 addresses, 105
 checking properties, 110
 specifying the partner, 103
Type of communication, 15

U

UDP
 addresses, 115
 checking, 119
 configuring, 112
 specifying connection partners, 113
Unspecified connection, 75