Bahnhofstrasse 18, 3280 Murten, Switzerland T +41 26 580 30 00, F +41 26 580 34 99 www.saia-pcd.com – www.sbc.support.com



Saia PCD7.D457VTCZ42 (VGA MB-Panel) Release Note

HW/FW Version of this PCD7.D457VTCZ42

HW version delivered HW Version B1 or higher Dedicated Firmware equipped from factory V1.18.13949_ela

This system is developed according to the international standard EN/IEC61131-2:2007 for controller and complies with CE conformity and most Shipping Approval Norms (like DetNorske Veritas and others). Details on request).

Additional technical specification:

UL Compliance CLISTED US 2D85 A IND.CONT.EQ.	Conformité UL selon les conditions suivantes
According to the following conditions	
For use on a Flat Surface of a Type 1 Enclosure.	Pour une utilisation sur une surface plane de
	« Enclosure Type 1 ».
Use 60/75°C copper (CU) wire only.	N'utiliser que des fils de cuivre, isolation 60/75°C.
Caution: do not connect directly to line voltage. Line	Attention: ne pas connecter directement à la tension
voltage must be supplied by a suitable, approved	de ligne. La tension de ligne conforme 24VDC doit
24 VDC isolating transformer having short circuit	provenir d'un transformateur isolé approuvé ayant
capacity not exceeding 100 VA maximum and with	une capacité de court-circuit ne dépassant pas
secondary protected by a 4A UL248 listed fuse".	100 VA maximum et dont le secondaire est protégée
	par un fusible 4 A UL248 classé.
This device is suitable for use in a 55 degrees C max	Ce dispositif est adapté pour une utilisation dans une
ambient.	ambiante de 55 degrés C max.

Firmware

- The FW can be updated via the USB or TCP/IP port. Please refer to the manual for the FW-Update procedure or check site below for new versions.
- By restoring the default parameter (via Setup Menu), your data will be restored based on ELA Default Settings.
 More information on request.

Further information and support

In order to maintain the lifetime of the Backlight LCD it is recommended to work at temperature between 10°C and 35°C. Please refer to the Manual for more information.

Further information and Software/COSinus-Updates are available on www.sbc-support.com

Disclaimer

The plant engineer contributes his share to the reliable operation of an installation. He is responsible for ensuring that controller use conforms to the technical data and that no excessive stresses are placed on it, e.g. with regard to temperature ranges, over voltages and noise fields or mechanical stresses. In addition, the plant engineer is also responsible for ensuring that a faulty product in no case leads to personal injury or even death, nor to the damage or destruction of property. The relevant safety regulations must always be observed. Dangerous faults must be recognized by additional measures and any consequences prevented. Consistent use of the diagnostic elements of the PCD, such as the watchdog, exception organization blocks (XOB) and test or diagnostic instructions shall be made.